

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 1 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

New Mexico Environment Department (NMED) Surface Water Quality Bureau (SWQB)

Standard Operating Procedure (SOP) for

CHEMICAL SAMPLING IN LOTIC ENVIRONMENTS

Approval Signatures

Miguel Montoya
Acting Quality Assurance Officer

Date

Lynette Guevara
Program Manager - Monitoring, Assessment and Standards Section

Date

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 2 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

1.0 Purpose and Scope

The purpose of this SOP is to describe the sample collection techniques, preservation and acidification requirements, equipment, and quality control activities associated with the chemical sampling of surface water in lotic environments. This SOP also applies to chemical sampling in lakes (Lentic environments). However, it does not include sample collection procedures for conducting lake sampling, refer to the SWQB SOP 12.1 for Lake Sampling protocols (NMED/SWQB 2020a).

2.0 Personnel Responsibilities

The Monitoring, Assessment and Standards Section (MASS) Program Manager coordinates with Monitoring Team Supervisor, and the Quality Assurance Officer (QAO) as applicable to ensure quality data is collected, verified, and validated to support program commitments.

The Quality Assurance Officer (QAO) is involved in the development and revision of this SOP to ensure the SOP meets the requirements of the SWQB's Quality Assurance Project Plan. The QAO; the MASS Program Manager; and SWQB subject matter experts (e.g., the MASS Monitoring Team Lead and field staff scientists) will determine if any revisions to this SOP are needed at a minimum of every two (2) years in accordance with the most current SOP 1.1 for the Creation and Maintenance of SOPs (<https://www.env.nm.gov/surface-water-quality/sop/>). Pending the review and approval of the document, the QAO will ensure the SOP is accessible through the SWQB's website.

The Monitoring Team Supervisor is responsible for delegation of responsibilities to Monitoring Team staff for chemical sampling for a particular survey according to Field Sampling Plan (FSP). Responsibilities include but are not limited to sampling, management of Monitoring Team staff, and ensuring staff adhere to sample frequency and sampling locations according to applicable FSP.

All SWQB personnel who collect chemical samples in lotic environments or process samples for chemical sampling in lotic environments are responsible for implementing procedures as prescribed in this SOP. SWQB staff who conduct procedures described under this SOP are required to sign the SOP acknowledgment statement for Chemical Sampling in Lotic Environments, prior to conducting procedures detailed in this SOP.

3.0 Background and Precautions

3.1 Background

All chemical water sampling activities in lotic and lentic waters shall comply with this SOP. Methods of sample collection, preservation, and handling used in this SOP shall comply with methods described in the following references or that are approved by EPA:

- "Guidelines establishing test procedures for the analysis of pollutants under the Clean Water Act," 40 CFR Part 136 or any test procedure approved or accepted by EPA using procedures provided in 40 CFR Parts 136.3(d), 136.4 and 136.5;
- Standard Methods for the Examination of Water and Wastewater, latest edition, American Public Health Association;

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 3 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

- Methods for Chemical Analysis of Water and Waste, and other methods published by EPA Office of Research and Development or Office of Water;
- Techniques of Water Resource Investigations of the USGS;
- National Handbook of Recommended Methods for Water-Data Acquisition, latest edition, prepared cooperatively by agencies of the U.S. Government under the sponsorship of the USGS;
- Annual Book of American Society for Testing and Materials (ASTM) Standards. Volumes 11.01 and 11.02, Water (I) and (II), latest edition, ASTM International;
- Federal Register, latest methods published for monitoring pursuant to Resource Conservation and Recovery Act regulations; or
- Federal Register, latest methods published for monitoring pursuant to the Safe Drinking Water Act regulations.
- State of New Mexico Standards for Interstate and Intrastate Surface Waters (20.6.4 NMAC). Most current amendments.

3.2 Procedural Precautions

If other stream sampling work (e.g., collection of stream flow, physical habitat measurements) is to be done simultaneously, or prior to the collection of chemical water samples, then collect chemical water samples upstream of any other work/disturbances to prevent contamination with the water chemistry or wait for disturbed water to flow past the collection site.

Chemical surface water samples must not be collected in the same assessment unit within 7 days so that data is compliant with assessment procedures for evaluation of water quality standards. See the most current Comprehensive Assessment and Listing Methodology (CALM) (NMED/SWQB 2023).

It is recommended to contact a staff member from the laboratory(s) and/or section lead prior to sampling to ensure analyses can be carried out within holding times. Analyses and holding times are impacted by holidays. If samples need to be rushed, due to an emergency or spill, contact the Monitoring Team Supervisor who will then contact the Chemistry Bureau Chief and the Surface Water Quality Bureau Chief to obtain approvals, ensure the proper coding is used for sample submission, and ensure laboratory staff are available after normal work hours/days to receive samples.

Organics sample containers, trip blanks, and hydrochloric acid (HCL) should be obtained from the SLD Organics Section. The Organics Section should be contacted at least one week prior to sample collection to ensure extractions and analyses can be carried out within holding times. Use self-adhering labels for organic sample bottles. Fill out labels on organics bottles and label containers before sampling to avoid having to write on wet surfaces. Only use pencils to fill out labels for organics to avoid sample contamination.

Total organic carbon and dissolved organic carbon require preservatives (phosphoric acid) provided by the laboratory. When utilizing SLD the Water Chemistry Section should be notified prior to sampling, to ensure all supplies are obtained prior to leaving for the sampling event.

Do not freeze samples collected in glass.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 4 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Site conditions or project-specific data collection objectives may necessitate the use of field procedures not included in this SOP. The use of field methods other than those presented in this SOP must be approved by the Program Manager or QAO for the project prior to use of modified field procedure or equipment. The change will need to be documented (e.g., email correspondence with Program Manager or OAO) and saved in applicable survey folder on the SWQB network shared folders.

3.3 Safety Precautions

Do not attempt to wade into a stream if the depth (in ft) multiplied by the velocity (in ft/s) equals or exceeds the "rule of ten" or 10 square feet per second (ft²/s). For example, a stream that is 2 ft deep, and has velocities of 5 ft/s or more, should be considered too dangerous to wade. Do not attempt to wade a stream if you feel it is unsafe, regardless of the outcome of the "rule of ten." Some channels have quicksand-like areas, deep holes, sharp rocks, excessive fallen logs, etc., that can lead to foot entrapment, injury, or falls. Staff should use best professional judgment to assess risks involved with data collection. Use gloves when working in waters suspected of having high bacterial contamination. Refer to SWQB's JHA for further safety precautions when conducting field work.

Consult the SWQB Chemical Hygiene Plan (CHP) or the SWQB Lab Safety Officer regarding acceptable practices for transferring concentrated acid in the Runnels Building Laboratory. Concentrated acid must always be transported in secondary containment vehicles and boats with a short-term exception allowed for pre-acidified sampling containers enroute from vehicles to stream or lake. Typically, in vehicles the SWQB ensures safety by transporting the secondary containment outside of where staff sit (e.g. the bed of truck or trunk of a car).

4.0 Definitions and Acronyms

For common definitions and acronyms not defined in this SOP, refer to the most up to date SWQB Quality Management Plan for Environmental Data Operations.

Analyte-Free Water – Water free of, or with the lowest attainable concentrations, of the analytes tested for in the requested analyses for a blank. Usually deionized (di), polished water obtained from the SLD Organics Section. Purer water may be necessary for some organic analyses.

Lentic – Inhabiting or situated in still, fresh water (as lakes or ponds).

Lotic – Inhabiting or situated in rapidly moving fresh water (as rivers or streams).

RID – is a unique reference ID number for samples submission.

Subject Matter Experts (SMEs) – Staff who are familiar with the purpose and procedure for accomplishing a task. All MASS Monitoring Team staff are considered and expected to be subject matter experts with all activities related to this SOP.

Sample – The medium, and any reagents or acids dissolved in the medium. The sample includes those materials that cannot be readily separated from the medium that is sampled.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 5 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Sampling Run –used to define the most common collecting period or grouping of sampling activities that are indicative of a SWQB MASS sampling operation. Typically, most samples are collected during multi-day collection events that depart and return to the office in a week (M-F). Blanks associated with a sampling run are assumed to represent a group of samples collected by the same staff, and using the same equipment, vehicle, reagents, and acids. When multiple, single day sampling runs are conducted within a given week that maintain constant variables as described above, the single day sampling runs are considered collectively as a single sampling run, provided the number of blanks collected is at least 10% of the environmental samples collected, preferably at a one blank sample per ten ambient sample frequency to allow for QC blank distribution.

Quality Control (QC) Sample Definitions

Field blank – A sample of analyte-free water and acid, if required, that is exposed to ambient environmental conditions at the sampling site and to transportation and storage conditions. Field blanks check for contamination from the sampling equipment, added reagents or acids, and from the environment. Field blanks are currently collected for *E. coli*. and total coliform and must be collected at a rate of 10% of the total number of samples.

Trip blank – A blank prepared with analyte-free water and acid that is made at the analytical facility, sealed, transported and analyzed with environmental samples. Trip blanks are not exposed directly to ambient environmental conditions at the sampling site. Trip blanks are transported to the lab in the same manner as environmental samples. The purpose of a trip blanks is to assess the potential for in-transit contamination of samples. Trip blanks are currently run only for VOCs at a frequency of 1 per sample run.

Reagent blank – A blank prepared in the lab using analyte-free water and reagent that is not exposed to ambient sampling conditions. Reagent blanks check for contamination from sample containers, analyte-free water and reagent.

Equipment blank – A sample prepared in the field, using analyte-free water and acid that has contacted all sampling equipment. Equipment blanks assess contamination from the sampling equipment and the acid, as well as from the ambient environment at the sampling site. Equipment blanks are currently collected for dissolved metals, hardness, and dissolved organic carbon and must be collected at a rate of 10% of the total number of samples.

Duplicate – A sample that is split from a common container after sample collection and analyzed as two samples. Duplicates are used to assess the precision of sample collection and analysis.

Replicate – A second sample that is collected within 15 minutes and within 1 meter of an initial sample.

5.0 Equipment and Tools

The following list (Table 1) includes equipment that may be necessary for surface water chemical sampling in lotic waters:

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 6 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Table 1. Sampling Equipment

SAMPLING SUPPLIES	GENERAL
Tablet or Laptop	Access authorization documents
Field sheets	Defensive driving certificate
Submittal forms	Cell phone
RID stickers	Coolers
Cartridge filters (0.45 µm and 10µm)	First aid kit
Acid washed silicon tubing	Flashlight
Cubitainers (quarts, gallons)	Maps
Geo pump, with appropriate power cord(s)	NMED ID
Kimwipes	Business cards
Acid kit with concentrated sulfuric, nitric acid, 10% HCL,	Shovel
Phosphoric acid	Toolbox or multitool
Pipets	Vehicle Kit
Nitrile gloves	Hat
Organics sample bottles (vials/bottles come in sets of 2)	Sunscreen
8oz glass amber bottle (DOC)	Nitrile power free gloves
Pencils	Rain gear
Sharpies (fat and fine point)	Sunglasses/polarized glasses
Gallon Cubie with tap water for cleaning equipment	Clipboard
Analyte-free water for preparing blanks	Boots/waders/sandals
Hammer	Garbage bags
Measuring tape (in feet and/or meters)	
Wading rod	
Flow meter and cable	
Potassium iodide (KI) starch Test Paper (cyanide samples)	
Nylon rope	
Metal bucket	
Plastic bucket	
Ice	
Coolers	
Pole sampler	
VOC Whirl-Packs	
Ascorbic acid (cyanide samples)	
VOC trip blanks	
Safety glasses	

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 7 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

6.0 Collection of Water Samples for Chemistry Analyses (PROCESS DESCRIPTION)

For planning and scheduling purposes, review the most current applicable FSP to confirm planned chemical sampling stations, requested analytical suite and other data needs before conducting field work. Reference ID (RID) stickers will need to be obtained from SLD before fieldwork commences. A chemical sampling event will need to be created in SQUID for each sampling station that will be sampled for internal projects. Typically this is completed by uploading the information from the Combined Data tab of the SLD Submittal Sheet into SQUID after sampling. Section 6.5 and 7.0 details to procedure in a step-by-step process.

Label all sample containers with the sample site location and sample type (e.g. dissolved metals) and place the pre-printed RID stickers on the lid of one liter and one-gallon flexible plastic containers or they can be placed on the sides of rigid plastic or glass containers. RIDs must be implied vertically so they can be scanned by the laboratory's Specimen and Receiving Section. When labeling sample containers, sample type is typically abbreviated (e.g., TM, DM, Nuts, TSS/TDS). Write the RID number on the container with a Sharpie®. A summary of the required containers, preservatives, and holding times for various analyses is given below (Table 2). The RID number of each sample container is recorded in the Activity ID's/RIDs section of the Stream and River Field Form. Before sampling, ensure RIDs on containers, and sample type match the RIDs for each analytical suite identified in the Stream/River Field Data Form.

Use self-adhering labels for organic bottles/vials. Fill out labels on organics bottles and label containers before sampling to avoid having to write on wet surfaces. Only use pencils to fill out labels for organics.

Instantaneous sonde measurements (i.e., temperature, specific conductance, salinity, dissolved oxygen, saturated dissolved oxygen, pH and turbidity) and stream flow are required to be collected at each chemical sample station. Data is recorded on the Stream/River Field Data Form. Instantaneous sonde measurements can be taken simultaneously with chemical samples, if taken so that the sediment is not disturbed at the chemical sampling point. Refer to SOP 6.1 Sondes (NMED/SWQB 2024) for information regarding collection of instantaneous measurements. Refer to SOP 7.0 Stream Flow Measurements (NMED/SWQB 2022) for information regarding flow measurements. If no flow is observed during sample run, ensure it is recorded on Stream and River Field Data Form and documented with a picture.

Collect water samples by immersing the sample container below the surface of the water with the container mouth facing upstream and all exposed flesh downstream from the opening of the container. Attempt to sample where the stream is flowing, well mixed and preferably more than 6 inches deep. Sample at mid-channel or as far away from the bank as possible. Avoid getting streambed sediment or water surface materials in the sample. For Equal-Width-Increment and Depth-Integrated Sample Collection Methods refer to Appendix A of this SOP.

It is not necessary to rinse new sampling containers, except for organic carbon samples (see organic carbon sampling below), with analyte-free or sample water before collecting the sample. If re-using sampling containers such as buckets or one-gallon cubitainers to collect water for multiple samples, rinse the container twice with ambient water before collecting the sample. When adding acid to cubitainers, never insert the pipettor below the top of the neck of the cubitainer and keep the pipettor at an angle above the cubitainer to reduce the chance of debris falling off the pipettor or your hand into

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 8 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

the sample. Pipettes need to be stored separately, in a dry secure container, where pipettes are not exposed to elements during transportation. Typically, container used for storage of pipettes would be similar to a Tupperware® container. Sample containers can be pre-acidified up to one week before use. Pre-acidified containers should be labeled and stored in secondary containment, such as coolers, with the lid propped open to minimize vapor buildup. Pre-acidified containers should not be opened in a closed area or near the face. Pre-acidified nutrient containers must be stored separately from pre-acidified total metals and dissolved metal containers so that cross contamination does not occur.

Use a bucket with a nylon rope, disposable bailer, or a pole sampler to collect water if sampling containers cannot be dipped directly in the water. Avoid contaminating the sample with debris from the rope and bridge, or other sampling platform. Use the first and second bucketful/container of water to rinse the bucket/container. Use the third bucket/container of water to collect the sample. Use a metal bucket when collecting organic samples and a plastic bucket when collecting metals samples. Do not let the metallic sonde components touch the sample water prior to collecting the sample from a bucket if sampling for metals.

6.1 Sample Collection and Processing for Specific Parameters

Refer to the SLD Submittal Form, an interactive submission form for analytical suite compositions, submission form can be accessed at <https://www.env.nm.gov/surface-water-quality/sop/> under related field forms for SOP 8.2.

The 1-quart and 1-gallon cubitainer used for chemical sampling in lotic environments are required to have a polyethylene liner and a polyethylene (or a fluoropolymer sampling vessel) cap to meet requirements described in the Background and Precaution section of this SOP.

6.1.1 TOTAL SUSPENDED SOLIDS (TSS), TOTAL DISSOLVED SOLIDS (TDS), ALKALINITY, CHLORIDE (CL), AND SULFATE (SO4)

Fill a 1-quart cubitainer. Keep sample on ice, at 6°C or less. Specific SWQB projects may require the preparation of a field blank by filling a 1-quart cubitainer with di water from SLD. Keep field blanks on ice, at 6°C or less. TSS, TDS, Alkalinity, CL, and SO₄ samples collected for development of the Clean Water Act (CWA) §303(d)/ §305(b) Integrated Report and List (IR), Total Maximum Daily Loads (TMDLs), or Water Quality Standard (WQS) amendments proposed by the SWQB do not require field blanks.

6.1.2 NUTRIENTS

Fill a 1-quart cubitainer and acidify with approximately 1 ml concentrated sulfuric acid (H₂SO₄) to a pH < 2. If using a pre-acidified container, do not overfill.

Specific SWQB projects may require the preparation of a field blank by filling a 1-quart cubitainer with DI water from SLD on site and acidifying with 1 ml of concentrated sulfuric acid. Keep field blanks on ice, at 6°C or less. Nutrient samples collected for development of the CWA IR, TMDLs, WQS amendments proposed by the SWQB do not require field blanks.

6.1.3 ORTHOPHOSPHATE

To prepare an environmental sample for orthophosphate analysis follow the steps below:

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 9 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

- Fill a cubitainer with at least 1 quart of stream, river, or lake water.
- Attach a 0.45 µm filter to one end of acid washed, 0.19-inch internal diameter silicone tubing. Do this by pulling the plastic bag containing the filter over the upstream barbed fitting on the filter until it perforates the bag. Open the tubing bag, expose about 5 inches of tubing, and push the tubing onto the exposed barbed fitting. Leave the plastic bag on the filter.
- Expose more of the tubing from the bag and insert the tubing into the Geo Pump and clamp (peristaltic pump).
- Remove the rest of the tubing from the bag and place the other end into the sample.
- Then remove the bag on the filter or push the downstream barb of the filter through the bag.
- Turn the pump on and pump at least 75 ml of sample through the filter, discard, and collect the remainder in a 1-quart cubitainer. Keep the filter to the side of the neck of the receiving cubitainer to prevent dirt and dust from falling into the sample.
- No Acidification is required per method.
- Keep the sample at 6°C or less.
- Place the used tubing in a separate bag from clean tubing and save for cleaning in the lab.
- Discard the 0.45 µm filter.
- Must be analyzed with 48 hours of sample collection

An equipment blank must be collected for dissolved metals and hardness. Fill a new cubitainer with at least a quart of DI water from SLD and follow the filtering instructions above starting at step 2. **Do not reuse** tubing and filters from blanks in environmental samples.

6.1.4 TOTAL METALS

Fill a 1-quart cubitainer and acidify with 2 ml of concentrated nitric acid (HNO₃). If using a pre-acidified container, do not overfill. Keep sample at ambient temperature. There are no blanks collected for total metals samples. Specific SWQB projects may require the preparation of a field blank by filling a 1-quart cubitainer with DI water from SLD on site and acidifying with 2ml of HNO₃.

6.1.5 TOTAL RECOVERABLE ALUMINUM

If stream turbidity is 30 NTUs or below, follow the instructions for total metals samples. If stream turbidity is greater than 30 NTUs, follow the instructions for dissolved metals samples but use a 10 µm filter instead of a 0.45 µm filter. There are no blanks collected for total recoverable aluminum samples.

6.1.6 HARDNESS AND DISSOLVED METALS

To prepare an environmental sample for hardness and dissolved metals follow the steps below:

- Fill a cubitainer with at least 1 quart of stream, river, or lake water.
- Attach a 0.45 µm filter to one end of acid washed, 0.19-inch internal diameter silicone tubing. Do this by pulling the plastic bag containing the filter over the upstream barbed fitting on the filter until it perforates the bag. Open the tubing bag, expose about 5

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 10 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

inches of tubing, and push the tubing onto the exposed barbed fitting. Leave the plastic bag on the filter.

- Expose more of the tubing from the bag and insert the tubing into the Geo Pump and clamp (peristaltic pump).
- Remove the rest of the tubing from the bag and place the other end into the sample.
- Then remove the bag on the filter or push the downstream barb of the filter through the bag.
- Turn the pump on and pump at least 75 ml of sample through the filter, discard, and collect the remainder in a 1-quart cubitainer. Keep the filter to the side of the neck of the receiving cubitainer to prevent dirt and dust from falling into the sample.
- Acidify the sample with 2 ml of concentrated nitric acid.
- Keep the sample at ambient temperature.
- Place the used tubing in a separate bag from clean tubing and save for cleaning in the lab.
- Discard the 0.45 μm filter.

Equipment blank must be collected for dissolved metals and hardness. Fill a new cubitainer with at least a quart of DI water from SLD and follow the filtering instructions above starting at step 2. **Do not reuse** tubing and filters from blanks in environmental samples.

6.1.7 RADIONUCLIDES

Fill two, 1-gallon cubitainers. Keep sample at ambient temperature. No blanks are collected for Radionuclide. SLD completes the preservative requirements.

6.1.8 CYANIDE

If chlorine is suspected, evaluate the sample water for the presence of chlorine. Samples from streams that are not immediately downstream from outfalls are unlikely to contain chlorine. If the chlorine is suspected to be present, samples can be checked using potassium iodide (KI)-starch test paper (or similar method).

Fill a 1-quart cubitainer with sample. If chlorine is present, remove it by adding ascorbic acid, a few crystals at a time, until a drop of sample produces no color on the starch test paper, then add one additional crystal.

After adding ascorbic acid (if necessary), preserve samples for cyanide analysis with sodium hydroxide. Preserve the sample with sufficient NaOH to produce a pH of 12 or greater. Most samples will require about 0.5 g solid NaOH per liter, approximately five pellets. Handle the pellets with wooden or plastic utensil or pour directly from the container. Keep samples on ice, at 6°C or less.

6.1.9 ORGANIC CHEMICALS

When collecting samples for organic compounds, wear clean nitrile gloves. Gloves are worn to prevent organic compounds that may be present on skin from contaminating samples. Avoid the false sense of security gloves may give; a gloved hand can still spread contamination. Put gloves on as close to the time of sample collection as possible. Avoid situations where a collector may come in contact with gasoline, such as, fueling vehicles or boats for field work. Use sampling

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 11 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

equipment with fluorocarbon polymer, glass, or metal components if components will directly contact samples to be analyzed for organic compounds. Do not use plastics other than fluorocarbon polymers. Follow any special procedures that may be provided by the laboratory.

6.1.10 VOLATILE ORGANIC COMPOUNDS (VOCs)

For each sample planned, obtain 2-40 ml vials in a Whirl-Pack from the SLD Organics Section. Fill the vials by submersion. Add 2 drops of 10% HCl (also obtained from the SLD Organics Section and less than 3 months old) to each vial. Fill the caps with sample water and cap the vials without leaving a headspace. Keep the vials together in a closed Whirl-Pack, on ice, at 6°C or less.

Obtain a VOC trip blank from the SLD Organics Section for each sample run that includes collecting VOC samples. The trip blank should be placed in a Whirl-Pack, then into a cooler on ice prior to leaving the laboratory. Remove the trip blank from the Whirl-Pack at a sampling station for approximately 1-2 minutes. Do not open the vials or acidify. Reinsert the trip blank into the Whirl-Pack and keep them in a cooler, on ice with the environmental samples until delivered to the lab.

Trip blanks and HCL that have be obtained prior to sampling should be stored in the walk-in cooler until taken to the field.

6.1.11 SEMI-VOLATILE ORGANIC COMPOUNDS (SVOCs), HERBICIDES, PESTICIDES

For each sample planned, obtain two 1L glass, amber colored bottles with Teflon lined caps and a bubble wrap sleeve for each from the SLD Organics Section. Fill both bottles by submersion and replace the lids underwater if possible. If the stream is not deep enough to submerge the sample container, use a third, new, 1-L glass amber bottle to fill the two sample bottles. A headspace is acceptable with SVOC samples. Keep bottles in bubble-wrap sleeves, obtained from the SLD organics section, before and after filling to avoid breakage. Store samples out of direct sunlight, on ice, at 6°C or less.

6.1.12 TOTAL RESIDUAL CHLORINE (TRC)

Collect samples for residual chlorine measurements directly below wastewater treatment plant outfalls when sampling for total residual chlorine for discharge monitoring from point sources. Fill the 10 ml sample cells provided in the HACH Chlorine Pocket Colorimeter kit to the line either directly from stream or from an aliquot of sample water. Wipe off excess water from the outside of sample bottles with lens paper or a KimWipe® and ensure that the glass is dry and clean (no fingerprints or smudges). Add the content of one DPD Total Chlorine Powder Pillow to one 10-ml sample cell and gently shake for 20 seconds. Let it stand for 3 to 6 minutes before reading. During this period, place the other 10 ml cell bottle (the blank) into the colorimeter cell holder, with the diamond mark facing you. Tightly cover the cell with the instrument cap and press zero. Remove the blank sample cell bottle from colorimeter cell holder. Place the cell with dissolved reagent into the colorimeter cell holder and cover tightly with instrument cap. Between 3 and 6 minutes after adding the reagent to the sample press READ and record the total residual chlorine value in the comment section of field sheet.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 12 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

6.1.13 ORGANIC CARBON

For each sample planned, obtain an 8oz amber glass bottle from the SLD Water Chemistry Section.

Total Organic Carbon (TOC) --

To prepare an environmental sample for TOC follow the steps below:

- Fill the 8 oz glass amber bottle and allow adequate volume for addition of preservative (provided by laboratory).
- Acidify the sample with concentrated phosphoric acid (H₃PO₄) to a pH ≤ 2.
- Keep samples on ice, at 6°C or less.

Dissolved Organic Carbon (DOC) --

To prepare an environmental sample for dissolved organic carbon follow the steps below:

- Fill a cubitainer with at least 1 quart of stream, river, or lake water.
- Attach a 0.45 µm filter to one end of acid washed, 0.19-inch internal diameter silicone tubing. Do this by pulling the plastic bag containing the filter over the upstream barbed fitting on the filter until it perforates the bag. Open the tubing bag, expose about 5 inches of tubing, and push the tubing onto the exposed barbed fitting. Leave the plastic bag on the filter.
- Expose more of the tubing from the bag and insert the tubing into the Geo Pump and clamp.
- Remove the rest of the tubing from the bag and place the other end into the sample.
- Then remove the bag on the filter or push the downstream barb of the filter through the bag.
- Turn the pump on and pump at least 75 ml of sample through the filter.
- When filling sample bottle keep the filter to the side of the neck of the receiving sample bottle to prevent dirt and dust from falling into the sample.
- Fill the 8oz glass amber bottle halfway (4oz) with filtered water as a rinse, cap and shake, and discard. Repeat this process 3 times total. Do not turn off the pump between rinses this was found to lead to an airlock which can cause tubing to disengage from filter.
- Fill the 8 oz glass amber bottle and allow adequate volume for addition of preservative. provided by SLD.
- Acidify the sample with concentrated phosphoric acid (H₃PO₄) to a pH ≤ 2.
- Keep samples on ice, at 6°C or less.
- Place the used tubing in a separate bag from clean tubing and save for cleaning in the lab.
- Discard the 0.45 µm filter.*

*After filtering the DOC sample, the same tubing and filter can be used to filter dissolved metals sample.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 13 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Equipment blank must be collected for DOC. Filter at least 1 liter of DI water through a new 0.45 µm filter and discard prior to filling the 8 oz glass amber bottle. After filtering at least 1 liter of DI water through filter then proceed to fill glass sample bottle. Acidify the sample with concentrated phosphoric acid (H₃PO₄) to a pH ≤ 2. Keep samples on ice, at 6°C or less. **Do not reuse** tubing and filters from blanks in environmental samples.

6.1.14 MICROCYSTIN

Sampling should be performed mid-summer to fall when HABs are most likely to bloom. Collect surface grab samples using a 1-liter Cubitainer™. If long, filamentous algae are present, leave headspace in Cubitainer™ and shake vigorously to ensure sample is homogenized. Pour the sample into two 40mL amber glass vials provided by the lab. Be careful not to overfill/spill reagents already present in the vials. Immediately store sample on ice away from sunlight. Samples must be maintained at 0-10° C until arrival at lab. Hold time for samples is not to exceed 14 days after collection, however, most laboratories require samples be delivered within 72 hours of collection. Be sure to notify laboratory as soon as possible prior to sampling to ensure they are prepared for sample processing.

6.2 Ambient Water Toxicity Testing

The USEPA Region 6 Laboratory conducts aquatic toxicity tests of water as part of the EPA Region 6 Ambient Toxicity Monitoring Program. An application process is required by EPA before selecting and scheduling ambient water toxicity testing. Contact the lab for further information.

6.3 Quality Control Sampling

Prepare and submit required blanks at a frequency of one per sampling run, unless otherwise indicated. Section 4.0 Definitions and Acronyms details the types of quality control samples utilized by the SWQB.

Currently, the SWQB only collects equipment blanks for dissolved metals, hardness, and DOC at a frequency of 10% of the total number of samples collected for a given fun.

The SWQB also collects a trip blank for VOC samples at a frequency of 1 per sample run.

E.coli and total confirm are not addressed in this SOP, however both require field blanks at a frequency of 10% of the total number of samples collected for a given fun.

See QAO or MASS Program Manager for more information.

6.4 Handling, Packaging, and Transporting Samples

After collection, place samples with temperature storage requirements in coolers. Ensure that all samples required to be kept cool are surrounded and in contact with enough ice to cool to approximately 6°C or less. It is important that containers are in an ice bath; i.e. in contact with water that is in contact with ice, especially in warm weather, to ensure adequate cooling. Make sure that all glass sampling containers are placed in bubble-wrap sleeves to protect from breaking. Bubble-wrap may insulate samples and prevent adequate cooling. It may be necessary to place additional ice in coolers. Check to see that samples are adequately labeled and that container lids are secure. Handling procedures and holding times are summarized below (Table 2).

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 14 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Samples taken for ambient water quality monitoring (i.e., for development of the CWA IR, TMDLs, WQS amendments proposed by the SWQB), do not require formal chain of custody procedures, the SWQB QAPP (NMED/SWQB 2021) provides more information on chain of custody procedures for specific data acquisition type conducted by the SWQB.

Table 2. SWQB chemical sample handling procedures and holding times.

Sample Type	Sample Container	Preservation and Storage	Maximum Holding Time
TSS and TDS	1-quart polyethylene cubitainer	On ice, approximately 6°C	7 days TSS – TDS
Alkalinity	1-quart polyethylene cubitainer	On ice, approximately 6°C	14 days**
Cl and SO ₄	1-quart polyethylene cubitainer	On ice, approximately 6°C	28 days**
Total Nutrients	1-quart polyethylene cubitainer	1.0 ml concentrated sulfuric acid, on ice, approximately 6°C	28 days
Orthophosphate	1-quart polyethylene cubitainer	Filter (µm.45) within 15 mins of sample collection, On ice, approximately 6°	48 hours
TOC/DOC	8 oz amber glass bottle	2-3 ml concentrated phosphoric acid, on ice, approximately 6°C	28 days
Cyanide	1-quart polyethylene cubitainer	5-7 pellets NaOH, 0.6g ascorbic acid if chlorine present, on ice, approximately 6°C	14 days
Total Metals	1-quart polyethylene cubitainer	2.0 ml concentrated nitric acid	28 days mercury – 6 months other*
Total Recoverable Aluminum	1-quart polyethylene cubitainer	Filter (10 µm) within 15 min of sample collection; 2.0 ml concentrated nitric acid.	6 months

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 15 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Sample Type	Sample Container	Preservation and Storage	Maximum Holding Time
Dissolved Metals / Hardness	1-quart polyethylene cubitainer	Filter (0.45 μ m) within 15 min; 2.0 ml concentrated nitric acid	28 days mercury – 6 months other*
Semivolatile Organic Compounds, Herbicides, Pesticides	Two 1-liter glass amber bottles (lab)	On ice, approximately 6°C	7 days
Volatile Organic Compounds	Two 40-ml glass vials (lab) in a Whirl-Pack	5 drops 10% HCl per vial (HCl provided by lab and prepared within 30 days of use), on ice, approximately 6°C	14 days
Radionuclides	Two 1-gallon polyethylene cubitainers	No preservative in the field, store at room temperature. Laboratory adds preservative	6 months
Microcystins	1-quart polyethylene cubitainer. Pour into two 40mL amber glass vials provided by the lab	On ice, approximately 0-10° C	14 days (SLD requires samples to be delivered with 72 hours of collection)

* Metals, except chromium VI and mercury maximum hold time 28 days

** Typically analyzed in conjunction with TSS/TDS (i.e., 1-quart polyethylene cubitainer for TSS, TDS, CL and SO₄)

6.5 Stream and River Field Data Form Completion

Either the paper or electronic versions of the Stream/River Field Data Form may be used to document sample collection. It is preferred that staff use the most up to date electronic version of the Stream/River Field Data Form. The forms are identical; however, the electronic form has built in data entry quality checks and automated functions. Use of the electronic form also allows batch laboratory submittal sheet generation and SQUID sample event upload. Station and RID information on either form may be entered in preparation for the sampling event.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 16 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

6.5.1 PAPER FORM

- Write the Project Name
- Enter site information, site ID, latitude, longitude, elevation, ecoregion, and driving directions
- Enter sampling event information: date and time, field staff, sonde and handset used, sampling equipment, sampling media, and indicate DO recalibration and pressure.
- Enter field measurements. Indicate missing values with “MDP”, if needed
- Enter flow condition rating
- Enter RID numbers, Analytical Suites, and sample processing and preservation information.
- Enter observed probable sources in the Sampling Notes section
- Enter streamflow measurement method and result. Add any streamflow comments to the Flow Comments section
- Add any other relevant sampling event comments to the Sampling Notes section
- If hard copy field sheets were used, they must be scanned and saved in survey folder upon returning to the office.

6.5.2 ELECTRONIC FORM

- Type in the Project Name.
- Select the Station Name from the drop-down list and enter RIDs.
- At sampling station enter sampling event information: date and time (use the “Now” button as a shortcut). Select from the drop-down lists: field staff, sampling equipment, sampling media, and indicate DO recalibration and enter pressure.
- Select flow condition rating.
- Enter RID numbers (the grey button on the right side of the RDI field adds the next number in sequence) and select Analytical Suites and sample processing/preservation information. If not already completed in the laboratory prior to sampling.
- Record instantaneous Sonde measurements on Stream River Field Data Form.
- Press the Probable Source Observations drop-down list button. Click on an observed probable source then press the “Select Probable Source” button. Repeat for all observed sources then press the “Add to Comments” button.
- Select the Streamflow Measurement method and enter the flow result. Add any streamflow comments to the Flow Comments Section.
- If the form is complete, press the “Publish Field Sheet” button. Resolve any error messages. If the form is not complete, press the “Save Draft” button to save the file and complete at a later time.
- The Publish Field sheet button creates a pdf of the completed field sheet.
- Published and draft files are saved in the C:\FIELD_SHEETS folder on the local hard drive.
- Upon returning to the office ensure pdf and excel files of fields sheets are transferred to project survey folder.

7.0 Data and Records Management

A Stream/River Field Data Form is filled out at every chemical sample station. All data obtained during chemical sampling is recorded on the Stream/River Field Data Form. The Stream and River Field Data

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 17 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Form is then published and filed in project folder after data collection is complete. The SLD Submittal sheet is then used to import important data from the Stream/River Field Data Form into SQUID using the macro-enabled processes in SLD submittal sheet. Refer to section below regarding SQUID upload instructions. Once uploaded into SQUID a person who did not create the field sheets or submittal/upload will verify that the information in SQUID matches the pdf version of the field sheet. Any corrections needed to the pdf will be added with the person's initials and date. Wrong information will be crossed out with a single line. Corrections in SQUID can be made if you have editing permission (see Monitoring Team Supervisor for more information). Once information is confirmed initial and date the top of the pdf where it says Verified. See figure1 below for details.

Figure 1. Stream/River Field Data Form

Once all field sheets in survey folder have been verified add VV complete with staff initials to the end of the folder name. See Figure 2 below for example.

Name	Date modified	Type	Size
April 18-20_VV_completeDA	1/19/2024 2:14 PM	File folder	
AugustVV_completeDV	1/11/2024 3:56 PM	File folder	
July 11-13_VV_completeDV	1/24/2024 3:53 PM	File folder	
June 21-22_VV_completeDV	1/24/2024 3:52 PM	File folder	
May 16-18_VV_completeDV	1/22/2024 7:28 AM	File folder	
Oct 3_LG and ES_VVcompleteDV	1/29/2024 2:45 PM	File folder	
Oct 11_12 DA and RGVVcompleteDV	10/19/2023 11:39 AM	File folder	

Figure 2. Management of Stream/Reiver Field Data Form

Stream/River Field Data Form file naming convention and shared folder location:

- Field sheets will be named automatically when published the naming convention is station number_date of sampling example 48DogCan002.7_2023-04-13. Files must be saved in the Field Sheets Folder in applicable survey. Each run will have a subfolder named based on the dates of the run. Example April 11-14. See Figure 2 for example of folder structure.
- A Bacteria Upload file is automatically generated and named by the macro-enabled submittal form. The File naming convention should be Bacteria_UL_date. The date is taken from first tab of the submittal form. See Figure 3 for an example of where the date is pulled from. Ensure the file is saved in the Bacteria Folder in applicable survey.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 18 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Survey:	Jemez 2021-2022
User Code:	55910
Collector's Name:	
Collector's Phone:	
Date+Time:	

Figure 3. SLD Submittal Form-Date and Time

- Upload data files are created for upload into SQUID by copying the data in the Combined Data tab of the submittal form to a blank spreadsheet. The naming convention must include UL_survey abbreviation_date submittal_initials. The initial should be the person who made the form example UL_SMW_11May2023_ES. Saved upload file in the Upload Folder in applicable survey.
- SLD Submittal spreadsheet must be saved in applicable survey folder in the Submittal Folder. The naming convention must include survey abbreviation_SLD_Submittal_your initials_date created. Example SMW_SLD_Submittal_JF_2023-01-02.

7.1 Uploading Chemical Sampling Event into Squid

To upload chemical sampling event data for a chemical sample station either upload the data manually or use the macro-enabled Excel spreadsheet.

7.1.2 UPLOAD CHEMICAL SAMPLING EVENT INTO SQUID USING MACRO-ENABLED SLD SUBMITTAL FORM

- Locate the most recent version of the macro-enabled SLD Submittal Form (available on the SWQB SOP website).
- Insert the correct survey name and year, user code for the survey (listed in the “lists” tab) and the collectors contact information as well as the date and approximate time of laboratory submittal.
- Make sure that all chemical sampling event data sheets for the sampling run are complete and published.
- In the SLD Submittal form instructions tab select “Select Files” and navigate to the project folder containing the published final drafts of the chemical sampling (Stream/River Field Data Form). Select all applicable chemical sampling events and flow events for upload.
- In the SLD Submittal form instructions tab select “create submittals.” The resulting submittals in the chemical suite tabs are the forms that are submitted to SLD when chemical samples are delivered for analysis. Each chemical suite sheet should contain the sample RID and a corresponding barcode (requires special computer software listed on the instructions tab), the collection date and time, the conductivity, and all appropriate header information.
- After sample RIDs are confirmed and successfully submitted to the laboratory for analysis, proceed with the chemical sampling event data upload in SQUID.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 19 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

- Ensure that all data is complete and create a .xlsx file from the combined data tab in the SLD Submittal form.
- In SQUID, select the “data management” tab at the upper left corner of the database, and select “imports” from the drop-down menu. In the “imports” sub-menu select “sampling event data.”
- The Import Sampling Event Data page should open. Select the applicable project from the project field menu, and then select “choose file.” Navigate to the .csv version of the sampling event data and then select “open.” In SQUID, select “upload file.”
- Ensure that there are no invalid records found with error messages. Error messages will appear as a red exclamation point in the “valid” column along with the message “X invalid records found.” Correct errors if invalid records are found. Once there are no invalid records, select “import all valid records.” A notification that upload was successful should appear. Most common error occurs if column AU (10_Micron_Filter_Used) is left blank. Change all blanks in column AU to FALSE to fix this error.
- Navigate to the project folder and select a station to ensure that the sampling events were successfully uploaded.

7.1.2. UPLOAD CHEMICAL SAMPLING EVENT DATA MANUALLY TO SQUID

- Navigate to the applicable project folder in SQUID by selecting the “project” tab on the navigation bar, then selecting the appropriate folder icon with a green arrow under the “View/Add Monitoring Locations” column.
- All stations that have been added to the selected project folder should appear. To upload a chemical sampling event to a particular station, select the folder icon with a green arrow under the “sampling events” column for that sampling station.
- In the Sampling Events page, select “add a new sampling event” in the top navigational bar. Select a sampling event type from the drop-down menu. For River/Stream chemical sampling event data select “RIVER/STREAM-CHEMICAL.” Select the “add new sampling event.”
- A sampling event details box will appear. Populate the fields in the general tab with the appropriate data.
- In the RIDS tab, enter the number of RIDs associated with that station. Enter the RID and select each corresponding Analyte Suite from the drop-down menu.
- In the Field Measurements tab enter all sonde data that was collected at the time of sampling. Indicate a flow condition rating associated with the event. This rating should correspond to the rating from the flow section of the Stream/River Field Data Form. ****Note:** that a flow event will not be created when chemical sampling events are manually uploaded and will have to be created for the station separately
- Select “save.” The chemical sampling event and associated RIDs should appear under the sampling events.
- Navigate to the project folder and select a station to ensure that the sampling events were successfully uploaded.

7.2 Upload of Chemical Analytical Results

The QAO uploads all chemical results completed by the State Laboratory Division and any other contracted laboratory. See QAO for additional details regarding result upload procedure.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 20 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

8.0 Quality Control and Quality Assurance

The SWQB controls the quality of chemical sampling in lotic environments by using standardized methods that are documented in this SOP. All personnel who collect conduct chemical sampling in lotic environments or process samples for lotic environments must be familiar with these protocols, sign acknowledgment form associated with this specific SOP and collect data in accordance with the procedures as they are defined in this SOP and all other applicable SOPs. In addition to standardized methods, proper training of field personnel represents a critical aspect of meeting the data quality objectives to fulfill the goals of the SWQB's QAPP (NMED/SWQB. 2021). Different types of quality control samples are collected to check for contamination and background levels of analytes that may be introduced through exposure to the environment, sampling containers, reagents and acids, and laboratory equipment used to collect and analyze the various types of samples.

Assurance of field data collection for chemical samplings is done through adherence to the procedure detailed in this and other applicable SOPs and oversight of the process by the QAO. If at any time the QAO determines this process is not being adhered to, the QAO has the authority to cease activities specific to this SOP with prior support and approval by the SWQB Bureau Chief and MASS Program Manager, until such a time that the issue can be resolved.

9.0 Related Forms

Stream/River Field Data Form
 Chemical Sampling Equipment Checklist
 Total Residual Chlorine Data Upload Form
 SLD submittal forms
 Equal Width Increment and Depth Integrated Samples

10.0 Revision History

Original. March 12, 2011.

Revision 1. January 23, 2012. Minor edits throughout SOP.

Revision 2. December 20, 2012. Updated Table 3 and additional language regarding total recoverable aluminum.

Revision 3. April 2, 2013. Minor edits to language and some clarification regarding preservation.

Revision 4. April 15, 2015. Changes to blank definitions and types. Added TSS/TDS/Cl/SO₄ blanks. Vacant, QAO; Douglas Eib, SME; Shelly Lemon, MASS Program Manager

Revision 5. March 14, 2022. Removed blank for SVOCs to follow QAPP; changed formatting to be consistent with SOP 1.1; added SLD submittal forms for organics and radionuclides; Removed discussion on compliance sampling because it is covered in SOP 8.3. Added details regarding the addition of chemical sampling data event in SQUID. Clarity and details added to the step-by step procedure. Added steps for field sheet completion. Added DOC sampling methods.

Title: Chemical Sampling in Lotic Environments	No: SOP 8.2	Page 21 of 21
	Revision 7	
Effective Date: 4/19/2024	Next Revision Date 4/19/2026	

Miguel Montoya, QAO; Chuck Dentino, SME; Kristopher Barrios, MASS Program Manager

Revision 6. May 2, 2022. Addressed minor grammatical mistakes, inconsistencies with SOP format numbering, and updated the next revision date to be consistent with details in SOP 1.1 Creation and Maintenance of SOPs. Staff who have signed the acknowledgment statement for the SOP for Chemical Sampling in Lotic Environments, Revision 5, are not required to sign the acknowledgment statement for SOP for Chemical Sampling in Lotic Environments, Revision 6 due to no substantive changes to objectives, procedures, or equipment detailed in SOP.

Revision 7. April 19, 2024. Addressed minor grammatical mistakes. Field blank requirement removed for the collection of nutrients, TSS, TDS, alkalinity, CL, and SO₄. The methods used to analyze specific parameters (i.e., nutrients, TSS, TDS, alkalinity, CL, and SO₄) do not require the use of a field blank during sample collection. Added microcystin sample collection to SOP. Updated procedure for the collection of equipment blanks for DOC. The process for data and records management was updated for clarity and file naming convention was added. Table 2 was deleted. Table 3 is now Table 2. Removed SME from approval page, all monitoring team staff are required to be SME for procedures detailed in this SOP.

11.0 References

New Mexico Environment Department/Surface Water Quality Bureau (NMED/SWQB). 2021. Quality Assurance Project Plan for Water Quality Management Programs. Available at: <https://www.env.nm.gov/surface-water-quality/protocols-and-planning/>

NMED/SWQB. 2023. Comprehensive Assessment and Listing Methodology (CALM). Available at: <https://www.env.nm.gov/surface-water-quality/calm/>.

NMED/SWQB. Standard Operating Procedures (SOPs):

NMED/SWQB. 2024. SOP 6.1 for Sondes. Available at: <https://www.env.nm.gov/surface-water-quality/sop/>

NMED/SWQB. 2022. SOP 7.0 for Stream Flow Measurements. Available at: <https://www.env.nm.gov/surface-water-quality/sop/>

NMED/SWQB. 2020a. SOP 12.1 Lake Sampling. Available at: <https://www.env.nm.gov/surface-water-quality/sop/>

NMED/SWQB. 2020b. SOP 1.1 for the Creation and Maintenance of Standard Operating Procedures. Available at: <https://www.env.nm.gov/surface-water-quality/sop/>