

Green Infrastructure Implementation in New Mexico

FREQUENTLY ASKED QUESTIONS AND GUIDANCE FROM NMED
AND OSE

SARAH HOLCOMB (NMED), JOHN ROMERO (OSE), STEVE HUDDLESON
(GWQB) AND NELLY SMITH (USEPA)

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Background

Green Infrastructure, as defined by the U.S. Environmental Protection Agency (USEPA), is a cost-effective, resilient approach to managing wet weather impacts that provides many community benefits. Because uncontrolled stormwater discharge contributes to many negative water quality impacts, Congress amended the Clean Water Act in 1987 to add stormwater point source discharges to the National Pollutant Discharge Elimination System (NPDES) permitting universe.

In 2006, the U.S. Environmental Protection Agency (USEPA) commissioned the National Research Council to provide an overall review of the NPDES Stormwater Program. The NRC published the report titled “Urban Stormwater Management in the United States¹” in 2009 to address their findings. The report addressed issues plaguing the stormwater program, and recommended ways to address dealing with stormwater discharges. One key suggestion the NRC made was to implement Green Infrastructure (GI) approaches in Municipal Separate Storm Sewer System (MS4) permits.

EPA decided to select three permitting pilots to implement several recommendations made in the Urban Stormwater Management report, including watershed-based permitting. One of those pilot permits was in the Middle Rio Grande (MRG)/Albuquerque area. During 2010-2014, EPA and NMED met regularly with potential permittees and other federal, state, regional and local agencies to provide input on the development of the permit.

On December 22, 2014, EPA announced issuance of the NPDES general permit for storm water discharges from MS4s located in the Middle Rio Grande watershed. The permit replaced both the individual NPDES permit NMS000101 issued on January 31, 2012, and the expired general permits NMR040000 and NMR04000I for discharges in this watershed area; combining coverage for regulated MS4s in the Albuquerque area into a single general permit. The permit was crafted to better address water quality and endangered species concerns within the watershed while accommodating and encouraging cooperative programs amongst permittees that could reduce compliance costs. The permit does not create a “new” permit obligation – it attempts to create a “better” option for a permit already required.

As the MRG entities began discussions about the new permit, it became apparent that water rights were going to be an important component of the implementation decisions surrounding GI approaches in New Mexico.

¹ <http://www.nap.edu/catalog/12465.html>

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Water in the desert is precious, from both a water quantity and a water quality perspective. The quantity side was recognized when the Rio Grande Compact was signed in 1938 between the states of Colorado, Texas and New Mexico, and the Country of Mexico, and approved by Congress. New Mexico is required to deliver a certain amount of water to the Texas state line each year, and depends on all sources of water to make those obligations.

New Mexico's water quantity law is based on prior appropriation – this is the legal principle that the first person in time to take a certain amount of water for beneficial use (agricultural, industrial or household) has the right to continue that same use of water for the same purpose. Users who would also like to use the water, may, if they do not negatively impair the rights of those first, or senior, users. First in time = first in right. Additionally, a user may not change the place or purpose of a Water Right such that it hinders another user's use.

USEPA's approach to Green Infrastructure was based on predevelopment hydrology – keeping the amount of water on site that historically would have infiltrated into the ground. This would prevent the resulting runoff from traveling over the ground to pick up pollutants on the way to the receiving waterbody. The technical details of this requirement are to require permittees to retain the 80th percentile storm event for redevelopment projects, and the 90th percentile event for new development projects. USEPA commissioned a contractor to determine the 80th and 90th percentile events for all urbanized areas across New Mexico, and the reports are available on the EPA website.²

The permit language contained in the Middle Rio Grande MS4 permit and the statewide small MS4 permit both contain references to compliance with New Mexico water quantity law, but through discussion, it was determined that further specific guidance was needed to address technical details of GI implementation to avoid violation of NM water quantity law. This guidance document intends to address those implementation issues to satisfy both water quantity and water quality obligations in the arid West. This is addressed in this document through Frequently Asked Questions (FAQs) and specific examples for ease of interpretation.

² https://www3.epa.gov/region6/water/npdes/sw/ms4/epa-nm_ms4_pre-development_hydrology_3-24-15_formatted_508.pdf (NM outside of the Albuquerque UA),
https://www3.epa.gov/region6/water/npdes/sw/ms4/nfs_albuquerque_report_april2014_v2.pdf (Albuquerque UA)

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

FAQs

1. Does the MS4 permit require permittees to retain water?

No, it does not. If the retention of water conflicts with applicable water quantity law, the permit does not specifically require permittees to retain or detain that water.

2. Is rooftop harvesting of rain water permissible?

Yes. The New Mexico Office of the State Engineer supports the wise and efficient use of the state's water resources; and, therefore, encourages the harvesting, collection and use of rainwater from residential and commercial roof surfaces for on-site landscape irrigation and other on-site domestic uses.

The collection of water harvested in this manner should not reduce the amount of runoff that would have occurred from the site in its natural, pre-development state. Harvested rainwater may not be appropriated for any other uses.

The OSE's Waterwise Guide to Rainwater Harvesting is included with this document as Appendix A.

3. Is rain water harvesting (storage for future use) from parking lots allowed?

Potentially. This would require a permit from the OSE to place this water to Beneficial Use.

4. If a property lies within a basin that has no outfall to our river system, can rain water harvesting be allowed from all areas?

In general, "Yes", but check with the local Water Rights District Office to be sure. A variance to the 96-hour Rule can be issued if the right circumstances exist and it can be proven that the water would not make it to a stream or river system. Rooftop harvesting of rain water is allowed statewide. Note: this water cannot be appropriated or put to any Beneficial Use without a permit from the OSE.

The "right circumstances" occur when water can be shown not to contribute to the local stream/river system. Ex: In the Las Cruces area where a Subdivision asked for a "Variance" to the 96-hour rule since the water would never make it to the Rio Grande anyway. We looked at it and determined that the water would not make it to the river so we granted the variance.

5. If a property uses underground chambers for storm water control and infiltration, does the 96-hour rule apply?

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

No, since the water is directly being infiltrated into the subsurface. Note: this water cannot be appropriated or put to any Beneficial Use without a permit from the OSE. Infiltration is not a beneficial use of water.

6. What types of BMPs are acceptable to OSE for controlling water flow or infiltration?

BMPs that retain water in ponds or impoundments should be minimized. The OSE cannot condone the use of practices that will promote evaporation because that is a water loss to the system.

Regarding flood control impoundments, water must be released within 96 hours, or a water right must be obtained to offset the effects to the stream or river system.

7. If a permittee decides to infiltrate stormwater, what are the parameters that infiltration must be conducted within?

Infiltration of stormwater in a manner that encourages the water to recharge underground aquifers is strongly encouraged by OSE. For example, if a regional facility managed by a flood control authority is used to infiltrate stormwater in an arroyo or other waterbody, these are areas that have a direct hydrological connection to underground resources. Infiltration in other areas will need to be evaluated by OSE. Typically, all such water must infiltrate within the 96-hour time frame.

Additionally, any other entity (not a flood control authority) that constructs a pond for flood control purposes also infiltrates water within 96 hours that has a direct hydrological connection to an aquifer or river. If infiltration is conducted within a pond or other structure that is not adjacent to an arroyo, OSE will need to evaluate the scenario.

- a. Is groundwater modeling required? Typically, no but some modeling could be required.

8. How does Dam Safety play into this discussion?

OSE has quoted regulations dealing with dam safety in this discussion for just that purpose – safety. If impoundments are being evaluated for flood control purposes (and this is unavoidable), any such structures also must follow the Dam Safety regulations.

9. What are acceptable BMPs for water rights compliance?

Basically, BMP's that don't retain or impound water for more than 96 hours and that are considered de-minimus in nature.

10. If I cannot avoid installing a pond or other impoundment, what must I do?

The New Mexico State Engineer must be included in the coordination if the proposed plan includes ponds and/or impoundments that will not drain in 96 hours. Individuals can ask the OSE for a variance or acquire water rights to offset the effects of the impoundment on the river. A variance to the 96-hour requirement altogether can be requested or a variance to increase the time allowed for infiltration can be requested. If a variance is requested either completely exempted or increasing the time frame for infiltration, we will require that the applicant submit proof to OSE in writing, making their case. OSE has issued several "Variance" requests in the past.

11. How does pre-development hydrology factor in to water rights?

OSE does not recognize pre-development hydrology in water rights allocation and appropriation. OSE depends on all water received to meet compact obligations across the state (both federal and interstate compacts). As stated above, rooftop capture and use of rainwater is permissible within pre-development hydrology limits.

12. How does EPA envision compliance with the following statement in the MRG MS4 and SMS4 permits?

Where applicable New Mexico water law limits the ability to fully manage the design standard volume on site, measures to minimize increased discharge consistent with requirements under New Mexico water law must still be implemented.

Compliance with NM Water Law may require some form of Permit from the OSE. It is best if those individuals considering any impoundment of water contact the local Water Rights District Office to check what regulatory options they might have to be consistent with NM Water Law. Even if it is anticipated to release water within 96 hours, it should be a best practice to discuss options with the local OSE field office.

Examples:

Detention pond that drains within 96 hours.

Infiltration gallery that needs maintenance and thus backs up with water.

13. It seems that municipalities should be able to keep the difference between historic (pre-development) runoff and developed runoff volumes. Why is it that they cannot?

This would be considered an Appropriation of water in an already fully appropriated system.

Green Infrastructure Examples

This next page provides links to other agencies who have put together green infrastructure toolkits or documentation. The purpose of including these materials is to start a targeted discussion of BMP appropriateness and applicability in the arid Southwest, and specifically in New Mexico. NMED is forming a workgroup to compile information on specific efforts in New Mexico and plans to compile this data for a comprehensive update to this document soon.

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

EPA's Toolkits and Information:

Region 9: <https://www3.epa.gov/region9/water/lid/>

Region 8: <https://www.epa.gov/region8/green-infrastructure>

EPA: <https://www.epa.gov/npdes/stormwater-planning>

New Mexico:

<http://xeriscapenm.com/xeriscape/>

<http://xeriscapenm.com/wp-content/uploads/2016/11/2016-Arid-Lid-small.pdf>

<http://nmwatercollaborative.org/projects-2/parkinglotretrofit/>

Arizona:

<https://wrrc.arizona.edu/publications/water-harvesting/low-impact-development-toolkit>

<https://sustainability.asu.edu/sustainablecities/wp-content/.../Mesa-LID-Report.pdf>

Virginia Tech:

<https://vtechworks.lib.vt.edu/handle/10919/5534/browse> (search for LID Fact Sheets)

Minnesota PCR:

<https://www.pca.state.mn.us/water/stormwater-management-low-impact-development-and-green-infrastructure>

Massachusetts:

http://www.mass.gov/envir/smart_growth_toolkit/pages/mod-lid.html

Texas:

<http://www.texaslid.org/>

Colorado:

http://www.casfm.org/stormwater_committee/LID-00.htm

www.law.du.edu/images/.../rmlui-sustainable-RMLUILowImpactDevelopment.pdf

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Example Scenarios for Implementation

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Examples

1. Developer A is building a new commercial development. The MS4 permit states that the developer must manage water generated by the 90th percentile storm on site. Is this permissible under State Water Law?
 - a. Yes, if it drains in 96 hours or a valid Water Right is attained and used to offset the effects to the river.
2. Developer B is planning to install an infiltration gallery at their new big box development in Albuquerque. They plan to collect rainwater from rooftops (up to the 90th percentile event – 0.61 inches), and route it to the infiltration gallery, underneath the parking lot. This development is not near an arroyo or the Rio Grande and it is uncertain how long the infiltrated water would take to reach an aquifer or a surface water body – is this infiltration practice ok?
 - a. Yes
3. Developer C is building a set of buildings in the Farmington and Las Cruces areas, taking advantage of the ability to redevelop lots that were recently acquired by their company. What are the specific compact obligations that the developer must keep in mind in each area?
 - a. The Compact obligation for the Farmington area is the Colorado River Compact on the San Juan and Animas/La Plata Rivers and the Rio Grande Compact for the Las Cruces area. If in both these areas the retention of water will take place and the time for this will exceed 96 hours they should contact the local District Office to discuss options.
4. Developer D in Santa Fe is planning to install pervious pavement in their parking lot to comply with the small MS4 general permit to manage the 80th percentile storm event on site. The engineer has looked at groundwater models and determined that infiltrated water would eventually make its way to one of the arroyos tributary to the Santa Fe River. Is this permissible in accordance with state water quantity law?
 - a. Yes

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Guidance to Implement Post- Construction Requirements under the 2014 EPA MRG MS4 Permit

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Menu of Some GI/LID Practices Suitable in Arid and Semi-Arid Conditions

Note: It is recommended that anyone wishing to implement the below examples contact the local OSE/Water Rights District Office to check with them before any decisions are made.

Table 1. Examples of BMPs for Traditional MS4s (e.g., cities and counties)

Menu of BMPs (GI/LID)	Benefits	Water Law Evaluation - OSE Permit Evaluation
<p><u>Rainwater Harvesting</u> Systems that collect and store rainfall for later use, slowing and reducing the volume of runoff.</p> <p>NM Site – Example: SSCAFCA Office Building.</p>	<p>This can be especially important in arid regions to reduce demands on increasingly limited water supplies.</p>	<p>None</p>
<p><u>Rain Gardens and Bioswales (bioretention or bioinfiltration cells.)</u> Shallow, vegetated areas that collect and absorb runoff from rooftops, sidewalks, and streets using plants and soil.</p> <p>NM Site - Example: Bear Canyon Senior Center</p>	<p>Versatile, attractive features that can be installed in almost any unpaved space.</p> <p>In arid and semi-arid regions like NM, native plants are drought resistant and hearty. Thus they require little to no maintenance once they are installed.</p> <p>When used in public areas they can provide shade and aesthetic benefits.</p> <p>Rain gardens can meet public landscaping requirements as well as provide stormwater benefits.</p>	<p>None</p>
<p><u>Living roofs or Eco-roofs</u> Roofs covered with plants that soak up and use rainwater.</p>	<p>They cool and insulate buildings, reducing energy use</p> <p>They are particularly cost effective where land values</p>	<p><u>None</u></p>

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

<p>NM Site – Example: UNM Pearl Hall roof</p>	<p>and traditional stormwater management costs are high.</p>	
<p><u>Planter Boxes</u> Rain gardens that collect and absorb runoff from rooftops, sidewalks, parking lots, and streets.</p> <p>NM Site – Example:</p>	<p>They have vertical walls that are ideal for space-limited sites in dense urban areas and can be used to provide seating and attractive plantings.</p>	<p>None</p>
<p><u>Permeable Pavements</u> Paved surfaces that let water soak into the ground, including pervious concrete, porous asphalt, and permeable interlocking pavers.</p> <p>NM Site Example: Open Space Visitor Center</p>	<p>They are particularly cost effective where land values are high and where flooding or icing is a problem.</p>	<p>None</p>
<p><u>Green Streets</u> Permeable pavement, bioswales, planter boxes, and trees integrated into street designs to soak up and store stormwater.</p> <p>Green streets combine more than one feature to capture and treat stormwater.</p> <p>NM Site Example: NM 47 Peralta</p>	<p>In addition to provide stormwater management, it provides heat reduction and energy conservation.</p>	<p>None</p>
<p><u>Green Parking</u> Permeable pavement, rain gardens, and bioswales</p>	<p>Besides collecting and absorbing stormwater, green parking can provide more</p>	<p>None</p>

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

incorporated into parking lot stalls, lanes, and landscaping. NM Site Example: Fidelity Investments	shade and reduce the heat emitted by pavements	
<u>Land Conservation</u> Protecting open spaces and sensitive natural areas NM Site Example: Various SSCAFCA projects	Protecting open spaces and sensitive natural areas within and adjacent to a city can reduce stormwater while providing recreational opportunities for city residents. Natural areas that should be a focus of this effort include riparian areas, wetlands, and steep hillsides	None
<u>Urban Tree Canopy</u> NM Site Example:	Provide shade and help to slow traffic.	None
<u>Downspout Disconnection</u> Rerouting rooftop drain pipes to direct rainwater to permeable areas NM Site - Example:	Redirecting downspouts to a landscaped area is a way to help reduce demands on landscape irrigation.	None

Table 2. Example BMPs for non-traditional MS4s including flood Control Authorities and DOTs (linear MS4s)

Note: It is recommended that anyone wishing to implement the below examples contact the local OSE/Water Rights District Office to check with them before any decisions are made.

Menu of BMPs (GI/LID)	Benefits	Water Law Evaluation - OSE Permit Evaluation
Bioswales (bioretention or bioinfiltration cells.)	Since bioswales are long and often run alongside of the road they do not take up large amounts of space and	None

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

	<p>can be used in urban, suburban, or rural settings.</p> <p>The vegetation in a bioswale filters the stormwater runoff and provides an attractive vegetated area</p>	
<p><u>Land Conservation</u> Protecting open spaces and sensitive natural areas</p> <p>NM Site Example:</p>	<p>Protecting open spaces and sensitive natural areas within and adjacent to a city can reduce stormwater while providing recreational opportunities for city residents. Natural areas that should be a focus of this effort include riparian areas, wetlands, and steep hillsides</p>	None
<p><u>Urban Tree Canopy</u></p> <p>NM Site Example:</p>	<p>Provide shade and help to slow traffic.</p>	None
<p>Other: AMAFCA Strategy: Regional water quality facility to capture and treat stormwater runoff from projects. They can be combined and enhanced with GI/LID components.</p>	<p>Regional water quality structures can be used to collect trash and debris before discharging to receiving waters. They can provide an excellent opportunity to efficiently collect and subsequently remove collected sediment and trash.</p>	

Notes:

- When LID and GI are implemented in a semi-arid climate, attention must be paid to that unique environment. With a dry climate and large temperature differences between summer and winter, native plants that are drought tolerant and low maintenance must be chosen that can withstand the harshness of the dry region.
- Green infrastructure in the semi-arid West can be specifically designed to address rapid freeze/thaw cycles, semi-arid conditions, and intermittent and unpredictable rainfall patterns.

Potential Scenarios and Considerations to Implement the Stormwater Quality Design Standard Required in the Permit

1. Evaluation of Potential Scenarios: Using Table 1 and Table 2, permittees may evaluate potential scenarios by selecting individual BMPs or combinations of BMPs to meet the performance standard in Part I.D.5.b.(ii)(b). The following are some considerations to be included in this analysis:
 - a. Permittees can use EPA predevelopment hydrology analysis (on site or neighborhood/sub-watershed scale) or may carry out their own analysis to mimic natural conditions (Options A or B in Part I.D.5.b.(ii)(b)).
 - b. Passive rainwater management has been successfully implemented in arid and semi-arid conditions. Passive rainwater management refers to the design of developed sites to collect runoff generated by impervious areas and direct it to nearby landscaped areas. It has three components:
 - ✓ a catchment area that collects rainwater (e.g., roof, street, or parking lot)
 - ✓ a distribution system that connects the catchment to the receiving landscape area (e.g., gutters and downspouts)
 - ✓ a receiving landscape area that can retain and infiltrate rainwater

Permittees may evaluate passive rainwater management as an option to implement post-construction requirements.

 - c. Evaluate all option:
 - ✓ Treat and release analysis.
 - ✓ Rain harvesting
 - ✓ Avoidance of creating impervious surfaces
 - d. For the selected scenarios, calculate the volume of runoff that will be managed to mimic natural conditions (include site constrain and conditions).
 - ✓ New Development Sites
 - ✓ Redevelopment Sites
2. Evaluate “Alternative Compliance for Infeasibility due to Site Constrains” under Part I.D.5.b.(v).

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

“When a Permittee determines a project applicant has demonstrated infeasibility due to site constraints specified in Part I.D.5.b.(v) to manage the design standard volume specified in Part I.D.5.b.(ii).(b) or a portion of the design standard volume on-site, the permittee may evaluate mitigation options in Part I.D.5.b.(v) (f).

3. Evaluation of mitigation options in Part I.D.5.b.(v) (f).
 - A. Off-site mitigation: Installation of green infrastructure features at another location.
 - B. Ground Water Replenishment Project: Implementation of a project that has been determined to provide an opportunity to replenish regional ground water supplies at an offsite location.
 - C. Payment in lieu: Contribute to a fund that is used for stormwater management projects elsewhere in the watershed.
 - D. Other: In a situation where alternative options A through C above are not feasible and the permittee wants to establish another alternative option for projects, the permittee may submit to the EPA for approval, the alternative option that meets the standard. e.g. AMAFCA Strategy

Appendix A


Municipality	80 th Percentile Event (in inches)	90 th Percentile Event (in inches)
Farmington UA	0.4	0.53
Santa Fe UA	0.5	0.68
Los Alamos UA	0.53	0.69
Albuquerque UA	0.48	0.65
Los Lunas UA	0.48	0.71
Las Cruces UA	0.55	0.78
El Paso UA (in New Mexico)	0.54	0.82

Frequently Asked Questions (FAQs)
Green Infrastructure Implementation in New Mexico
March 2017

Appendix A: OSE's Waterwise Rooftop Harvesting Guide

Rainwater Harvesting

SUPPLY FROM THE SKY



A PUBLICATION OF THE CITY OF ALBUQUERQUE



LETTER FROM THE MAYOR

Dear Neighbor,

On behalf of the City of Albuquerque, I am pleased and excited to present *Rainwater Harvesting: Supply from the Sky*. This guide was developed by the City's Water Conservation Office to assist city residents and businesses in the campaign to save water.

Achieving our community's ambitious water conservation goals will not come easily. Doing so will require that we as a community adopt a "water ethic," and that all of us make conservation part of our daily lives. I believe this guide can help in that regard because rainwater harvesting, by its very nature, reconnects people to the environment they live in. It teaches natural limits while showing that human ingenuity can stretch those limits through improvements in efficiency and overall water management. Indeed, rainwater harvesting is the perfect combination of supply-side and demand-side management techniques, increasing the supply of water while simultaneously promoting demand-side reductions. Perhaps most importantly, rainwater harvesting fosters an awareness of one's personal water use and of the amount of water available from rainfall alone. And, it's something anyone can do.

So read this guide, share it with your friends and neighbors, and let us know what you think about it. But above all, use it to take advantage of the "supply from the sky." If each of us does just a little to act on the advice contained within these pages, we will have taken a big step toward ensuring an adequate water supply for our community today and in the future.

Sincerely,



Jim Baca, Mayor
City of Albuquerque



"Achieving the higher savings will require that the City effectively reach out and engage large segments of the public in a shared mission to save water. In that regard, Albuquerque will need to establish a water ethic that ripples throughout the entire community, one that can fuel the program to go above and beyond what has been done elsewhere."

From:
Water Conservation Rates and Strategy
Analysis, March 1995

ACKNOWLEDGEMENTS

CITY OF ALBUQUERQUE

Jim Baca, Mayor

PUBLIC WORKS DEPARTMENT

Larry Blair, Director

WATER RESOURCES DIVISION

John Stomp, Manager

Jean Witherspoon, Water Conservation Officer

ALBUQUERQUE CITY COUNCIL

President

Michael Brasher, District 9

Vice President

Alan Armijo, District 1

Alan B. Armijo, District 1

Brad Winter, District 4

Tim Kline, District 5

Hess Yntema, District 6

Mike McEntee, District 7

Greg Payne, District 8

Michael Brasher, District 9



In large part this publication duplicates a rainwater harvesting guide published by the Arizona Department of Water Resources (ADWR) in September, 1998. Titled *Harvesting Rainwater for Landscape Use*, it was prepared by Patricia H. Waterfall, Extension Agent with the Pima County Cooperative Extension Low 4 Program, with editorial assistance from Joe Gell, Editor, Water Resources Research Center, University of Arizona; Dale Devitt, Professor, Soil and Water, University of Nevada/Reno; and Christina Bickelmann, Water Conservation Specialist, Arizona Department of Water Resources, Tucson Active Management Area. Silvia Rayces prepared the artwork. We are grateful to ADWR for allowing us to borrow freely from their publication.

This guide was revised to incorporate New Mexico-specific data and reformatted to accommodate the needs of the City of Albuquerque. Draft production was handled by Kevin Bean, of K.M. Bean Environmental Consulting; Doug Bennett, Albuquerque's Irrigation Conservation Manager; and Eva Khoury, an Intern with the Water Resources Division of the Albuquerque Public Works Department. Technical assistance was provided by Andrew Selby of the Mayor's Office, and by Kay Lang of the Albuquerque Environmental Health Department. Cooney, Watson & Associates handled final production. Final design was provided by Ken Wilson Design.

TO ORDER:

Albuquerque residents may order this document from the City's Water Conservation Office, P.O. Box 1293, Albuquerque, NM 87103. 505-768-3655 (phone), 505-768-3629 (fax), 768-2477 (TTY) or Relay NM 1-800-659-8331. (www address: <http://www.cabq.gov/resources>.)


If you live outside of Albuquerque, please contact the Office of the State Engineer, Water Use and Conservation Bureau, P.O. Box 25102, Santa Fe, N.M. 87504-5102. Orders may also be placed by phone at 1-800-WATERNM.

TABLE OF CONTENTS


Letter from the Mayor	i
Acknowledgements	ii
Table of Contents	iii
Introduction	1
Rainwater Harvesting System Components	2
Simple Rainwater Harvesting Systems	3
Simple Rainwater Harvesting System Design and Construction	4
Complex Rainwater Harvesting Systems	6
Elements of a Complex Rainwater Harvesting System	7
Complex Rainwater Harvesting System Design and Construction	10
Maintenance Checklist	17
Appendix I: Inches of Average Monthly Rainfall for NM Towns	18
Appendix II: Runoff Coefficients	19
Appendix III: Average Evapotranspiration for Selected Areas in NM	19
Appendix IV: Plant Water Use Coefficients	20
Appendix V: Supply and Demand Worksheets	21
Appendix VI: Guidelines for Rain Gutters and Downspouts	23
Appendix VII: How to Build a Rainbarrel	24
Appendix VIII: Where to Go for More Information	25
Notes	26



INTRODUCTION



Series of water harvesting basins on a slope.



Parking lot draining into concave lawn area.

IMPORTANT NOTES

1. This Guide applies to landscape uses of harvested water only. The use of rainwater for drinking is beyond the scope of this publication.
2. Before you start, check with your local building, zoning and environment departments to determine what plumbing requirements, height and local restrictions, neighborhood covenants, or other regulations or guidelines might apply to your project.

In the arid Southwest rainfall is scarce and frequently erratic. These conditions require that water be used as efficiently as possible, and that we take full advantage of what little rain we do receive to help meet our water needs.


Rainwater harvesting is the capture, diversion, and storage of rainwater for landscape irrigation and other uses. Although rainwater can serve as a source of potable water, this guide focuses on landscape uses because they: 1) account for a significant percentage of total water demand; 2) are less essential and therefore more easily reduced than water used for other purposes; and 3) need not meet stringent drinking water standards. In many communities landscaping accounts for 30 to 50 percent of total water use. In Albuquerque, about 15 billion gallons of water a year are used for landscape irrigation.

Rainwater harvesting can reduce the use of drinking water for landscape irrigation. Coupled with the use of native and desert-adapted plants, rainwater harvesting is an effective water conservation tool because it provides “free” water that is not from the municipal supply. Water harvesting not only reduces dependence on groundwater and the amount of money spent on water, but it can reduce off-site flooding and erosion as well. If large amounts of water are held in highly permeable areas (areas where water penetrates the soil quickly and easily), some water may percolate to the water table.


Rainwater is the best source of water for plants because it is free of salts and other minerals that can be harmful to root growth. When collected, rainwater percolates into the soil, forcing salts down and away from the root zone. This allows for greater root growth, which increases the drought tolerance of plants.

Rainwater harvesting can be incorporated into large-scale landscapes, such as parks, schools, commercial sites, parking lots, and apartment complexes, as well as small-scale residential landscapes. The limitations of water harvesting systems are few and are easily met by good planning and design. There are many water harvesting opportunities on developed sites, and even small yards can benefit from water harvesting. And, water harvesting can easily be planned into a new landscape during the design phase. So whether your landscape is large or small, the principles outlined in this manual apply.


RAINWATER HARVESTING SYSTEM COMPONENTS



Simple system—roof catchment, channel, and planted landscape holding area.



Simple system—roof catchment, gutters, and bermed landscape holding area.



Simple system—roof catchment, gutters, downspouts, and french drain.


All rainwater harvesting systems have three main components: the supply (Rainfall), the demand (Plant Water Requirement), and the system that moves water to the plants (Water Collection and Distribution System). Water harvesting systems can be divided into Simple and Complex systems. In general, simple systems immediately distribute rainwater to planted areas, whereas complex systems store some or all of the rainwater in a container for later use.

Rainfall. Rainwater “runoff” refers to rainwater that flows off a surface. If the surface is impermeable, runoff occurs immediately. If the surface is permeable, runoff will not occur until the surface is saturated. Runoff can be harvested (captured) and used immediately to water plants or stored for later use. The amount of rain received, its duration and intensity all affect how much water is available for harvesting. The timing of the rainfall is also important. If only one rainfall occurs, water percolates into the dry soil until it becomes saturated. If a second rainfall occurs soon after the first, more water may run off because the soil is already wet.

Plant Water Requirements. The type of plants selected, their age and size, and how closely together they are planted all affect how much water is required to maintain a healthy landscape. Because rainfall is scarce in arid regions, it is best to select plants with low water-use requirements and to limit planting densities to reduce overall water need. Native plants are well-adapted to seasonal, short-lived water supplies, and most desert-adapted plants can tolerate drought, making them good choices for landscape planting.

Water Collection and Distribution Systems. Most people can design a rainwater collection and distribution system to meet the needs of their existing site. Designing a system into new construction allows one to be more elaborate and thorough in capturing and routing rainwater. In the case of very simple collection and distribution systems, the payback period may be almost immediate.

SIMPLE RAINWATER HARVESTING SYSTEMS



Crescent-shaped landscape holding areas on a slope.


A simple water harvesting system usually consists of a catchment, a distribution system, and a landscape holding area, which is a concave or planted area with an earthen berm or other border to retain water for immediate use by the plants. A good example of a simple water harvesting system is water dripping from the edge of a roof to a planted area or diversion channel located directly below the drip edge. Gravity moves the water to where it can be used. In some cases, small containers are used to hold water for later use.

Catchments. A catchment is any area from which water can be collected, which includes roofs, paved areas, and the soil surface. The best catchments have hard, smooth surfaces, such as concrete or metal roofing material. The amount of water harvested depends on the size, surface texture, and slope of the catchment area.


Distribution Systems. These systems connect catchments to the landscape holding areas. Distribution systems direct water flow, and can be simple or sophisticated. For example, gutters and downspouts direct roof water to a holding area, and gently sloped sidewalks distribute water to a planted area. Hillsides provide a perfect situation for moving water from a catchment to a holding area. Channels, ditches, and swales (shallow depressions) all can be used to direct water. (If desired, these features can be lined with plastic or some other impermeable material to increase their effectiveness and to eliminate infiltration in areas where it isn't wanted.) Elaborate open-channel distribution systems may require gates and diverters to direct water from one area to another. Standard or perforated pipes and drip irrigation systems can be designed to distribute water. Curb cutouts can channel street or parking lot water to planted areas. If gravity flow is not possible, a small pump may be required to move the water.

Landscape Holding Areas. These areas store water in the soil for direct use by the plants. Concave depressions planted with grass or plants serve as landscape holding areas. These areas contain water, increase water penetration into the soil, and reduce flooding and erosion. Depressed areas can be dug out, and the extra soil used to form a berm around the depression. With the addition of berms, moats, or soil terracing, flat areas also can hold water. One holding area or a series of holding areas can be designed to fill and then flow into adjacent holding areas through spillways (outlets for surplus water).

SIMPLE RAINWATER HARVESTING SYSTEM DESIGN & CONSTRUCTION



Site plan showing drainage patterns and landscape holding areas (aerial view).



Tree dripline and basin edge.

FREE XERISCAPE GUIDE

The City of Albuquerque and the New Mexico Office of the State Engineer offer a free, full-color How-to Guide to Xeriscaping that contains many examples of low-water use, drought-tolerant plants. To request your copy, call 768-3655 (Albuquerque residents), or 1-800-WATERNM (all others).

Step #1. Design the Collection and Distribution System.

By observing your landscape during a rain, you can locate the existing drainage patterns on your site. Use these drainage patterns and gravity flow to move water from catchments to planted areas.

If you are harvesting rainwater from a roof, extend downspouts to reach planted areas or provide a path, drainage, or hose to move the water where it is needed. Take advantage of existing sloped paving to catch water and redistribute it to planted areas. The placement and slope of new paving can be designed to increase runoff. If sidewalks, terraces, or driveways are not yet constructed, slope them 2 percent (1/4 inch per foot) toward planting areas and use the runoff for irrigation. Soil can also serve as a catchment by grading the surface to increase and direct runoff.


Step #2. Design Landscape Holding Areas.

Next, locate and size your landscape holding areas. Locate landscape depressions that can hold water or create new depressions where you want to locate plants. (To avoid structural or pest problems, locate holding areas at least 10 feet from any structures.) Rather than digging a basin around existing plants, construct level berms or moats on the surface to avoid damaging roots. Do not mound soil at the base of trees or other plants. Holding areas around existing plants should extend beyond the “drip line” to accommodate and encourage extensive root systems. Plants with a well-developed root system have a greater tolerance for drought because the roots have a larger area to find water. For new plantings, locate the plants at the upper edge of concave holding areas to encourage extensive rooting and to avoid extended flooding. For both existing and new landscapes you may want to connect several holding areas with spillways or channels to distribute water throughout the site.


Step #3. Select Plant Material.

Proper plant selection is a major factor in the success of a water harvesting project. Native and desert-adapted plants are usually the best choices. Some plants cannot survive in the actual water detention area if the soil is saturated for a long period of time, so careful plant selection for these low-lying areas is important. Select plants that can withstand prolonged drought and prolonged inundation, such as native or adapted plants. If you intend to plant in the bottom of large, deep basins, low-water use, native riparian trees may be the most appropriate plant choice.

SIMPLE RAINWATER HARVESTING SYSTEM DESIGN AND CONSTRUCTION



Gabion in a stream bed.



Permeable paving blocks with grass.

STOP!

Call 1-800-321-ALERT (2537) before you dig to locate utility lines on your property. This will minimize the potential for line breaks, and could save your life.

To take advantage of water free falling from roof downspouts (canales), plant large rigid plants where the water falls or hang a large chain from the downspout to the ground to disperse and slow the water. Provide a basin to hold the water for the plants and also to slow it down. It may be necessary to place rocks or other hard material under the downspout to break the water's fall and prevent erosion. If you're working with a sloped site, large, connected, descending holding areas can be constructed for additional plants.

Seeding is another alternative for planting holding basins. Select seed mixes containing native or desert-adapted wildflowers, grasses, and herbaceous plants. Perennial grasses are particularly valuable for holding the soil and preventing erosion and soil loss.

Take care not to compact soils in landscape holding areas: this inhibits the movement of water through the soil. If the soil is compacted, loosen it by tilling. If the soil is too sandy and will not hold water for any length of time, you may wish to add composted organic matter to the soil to increase its moisture-holding potential. (This is not necessary with native or desert-adapted plants.) After planting, apply a 1.5 - 2 inch layer of mulch to reduce evaporation (but realize organic mulches may float).

HARVESTING WATER TO REDUCE FLOODING AND EROSION

Rain falling on impermeable surfaces generates runoff. In sufficient volumes runoff is a powerfully erosive force, scouring away bare soil and creating pockmarked roads. Because roofs, roads, and parking lots are impermeable surfaces, in urban areas even moderate rainfall produces large amounts of runoff. Controlling runoff to prevent flooding and erosion is a major public expense.


Water harvesting can reduce these problems. Crescent-shaped berms constructed around the base of a plant are useful for slowing and holding water on slopes. Gabions (a stationary grouping of large rocks encased in a wire mesh) are widely used to contain water and reduce erosion. French drains (holes or trenches filled with gravel) can also hold water for plant use. Permeable paving materials, such as gravel, crushed stone, and open or permeable paving blocks, stabilize soil on steep slopes and allow water to infiltrate into the soil to irrigate trees and other plants with large, extensive root systems. Another option on steep slopes is terrace grading to form stairstep-like shelves. By slowing runoff and allowing it to soak into the ground, rainwater harvesting can turn a problem into an asset.

COMPLEX RAINWATER HARVESTING SYSTEMS

Water harvesting cannot provide a completely reliable source of irrigation water because it depends on the weather, and the weather is not dependable. To maximize the benefits of rainwater harvesting, storage can be built into the system to provide water between rainfall events. New Mexico's rainy season, for example, usually begins in mid-summer and runs through the fall, with drier periods in between. During the summer "monsoons" a heavy rain may produce more water than is needed by a landscape. (Plants are well watered once their rootzones have been thoroughly wetted: at this point water may begin to run off or stand on the surface.) With a complex water harvesting system this excess water is stored for later use.


A frequently-asked question is whether a complex water harvesting system can collect and store enough water in an average year to provide sufficient irrigation for an entire landscape. The answer is yes, so long as the amount of water harvested (the supply) and the water needed for landscape irrigation (the demand) are in balance. Storage capacity plays a big role in this equation by making water available to plants in the dry seasons when rainfall alone is insufficient.

Rainwater harvesting systems that include storage result in both larger water savings and higher construction costs. These complex systems are more appropriate for larger facilities or for areas where municipal or other water supplies are not available, and they may require professional assistance to design and construct. With such a system, the cost of storage — which includes the storage container, excavation costs, pumps and wiring, as well as additional maintenance requirements — is a major consideration. The investment payback period may be several years, which means that one's personal commitment to a "water conservation ethic" may come into play in determining whether such an investment makes sense. For most people, the appropriate choice is to harvest less than the total landscape requirement. Another option is to reduce water demand by reducing planting areas or plant densities, or by replacing high-water use plants with medium or low-water use ones. This reduces the supply required and the space required to store it, and is, therefore, less expensive.




Complex water harvesting system with roof catchment, gutter, downspout, storage, and drip distribution system.

ELEMENTS OF A COMPLEX RAINWATER HARVESTING SYSTEM



Catchment area of flat roof = Length x width



Catchment area of sloped roof (both sides) = Length x width

Complex rainwater harvesting systems include catchments, conveyance systems (to connect catchments to storage containers), storage, and distribution systems (to direct water where it is needed). Each of these elements is discussed below.


Catchments. The amount of water or “yield” that a catchment will provide depends on its size and surface texture. Concrete, asphalt, or brick paving and smooth-surfaced roofing materials provide high yields. Bare soil surfaces provide harvests of medium yield, with compacted clay soils yielding the most. Planted areas, such as grass or groundcover areas, offer the lowest yields because the plants hold the water longer, thereby allowing it to infiltrate into the soil. (This is not necessarily a problem, depending on whether you want to use the collected water directly or store it for later use.)

Conveyance Systems. These systems direct the water from the catchment area to the storage container. With a roof catchment system, either canales (from which water free-falls to a storage container) or gutters and downspouts are the means of conveyance. Gutters should be properly sized to collect as much rainfall as possible. (See Appendix VI for guidelines on gutters and downspouts.)

TABLE-1
ANNUAL APPROXIMATE SUPPLY FROM ROOF CATCHMENT

Inches/ Rainfall	Gallons/ Square Foot
0	0
1	0.6
2	1.3
3	1.9
4	2.5
5	3.1
6	3.7
7	4.4
8	5.0
9	5.6
10	6.2
11	6.8
12	7.5
13	8.1
14	8.7
15	9.3

ELEMENTS OF A COMPLEX RAINWATER HARVESTING SYSTEM



Roofwasher system


Storage. Storage allows full use of excess rainfall by making water available when it is needed. Before the water is stored, however, it should be filtered to remove particles and debris. The degree of filtration necessary depends on the size of the distribution tubing and emission devices (drip systems would require more and finer filtering than water distributed through a hose). Filters can be in-line or a leaf screen can be placed over the gutter at the top of the downspout. Always cover the storage container to prevent mosquito and algae growth and to keep out debris.

Many people divert the first part of the rainfall to eliminate debris from the harvested water. The initial rain “washes” debris off the roof; the later rainfall, which is free of debris and dust, is then collected and stored. The simplest roof-washing system consists of a standpipe and a gutter downspout located ahead of the cistern. The standpipe is usually 6 - 8 inch PVC equipped with a valve and cleanout at the bottom. Once the first part of the rainfall fills the standpipe, the rest flows to the downspout connected to the cistern. After the rainfall, the standpipe is drained in preparation for the next rain event. Roof-washing systems should be designed so that at least 10 gallons of water are diverted to the system for every 1,000 square feet of collection area. Several types of commercial roof washers are also available.

TABLE-2
CALCULATING ROOFWASHER SYSTEM CAPACITY

Pipe Diameter	Capacity
4 inches	= 0.65 gallons/foot
6 inches	= 1.47 gallons/foot
8 inches	= 2.61 gallons/foot


Storage containers can be located under or aboveground, and made of polyethylene, fiberglass, wood, concrete, or metal. Underground containers are more expensive due to the cost of soil excavation and removal. Pumping water out of these containers adds to their cost. Ease of maintenance should also be considered. Swimming pools, stock tanks, septic tanks, ferrocement culverts, concrete blocks, poured-in-place concrete, or building rocks can be used for underground storage.



Roof catchment with sloping driveway, french drain, and underground storage.

Examples of aboveground containers include 55-gallon plastic or steel drums, barrels, tanks, cisterns, stock tanks, fiberglass fishponds, and swimming pools. Buildings or tanks made of concrete block, stone, plastic bags filled with sand, or rammed earth also can be used. Costs depend on the system, degree of filtration, and distance between the container and place of use. Look under “Tanks,” “Feed Dealers,” “Septic Tanks,” or “Swimming Pools” in the Yellow Pages to locate storage containers. Salvaged 55-gallon drums may be available from local businesses, but should you choose to use them, take care to use only those drums that are free of any toxic residues.

ELEMENTS OF A COMPLEX RAINWATER HARVESTING SYSTEM



Vine used to screen storage tank.

STORAGE CONTAINER SAFETY

Storage units should be covered, secure from children, and clearly labeled as unfit for drinking. If containers are elevated, a strong foundation should be used. Containers should be opaque and, if possible, shielded from direct sunlight to discourage the growth of algae and bacteria. Regular inspection and maintenance (cleaning) are essential.


Locate storage near or at the end of downspouts. If storage is unsightly, it can be designed into the landscape in an unobtrusive place or hidden with a structure, screen, and/or plants. In all cases, storage should be located close to the area of use and placed at an elevated level to take advantage of gravity flow. Ideally, on a sloped lot the storage area is located at the high end of the property to facilitate gravity flow. Another option is to locate several smaller cisterns near where water is required, because they are easier to handle and camouflage. If the landscaped area is extensive, several tanks can be connected to increase storage capacity. In the event that rainfall exceeds storage capacity, alternative storage for the extra water must be found. A concave planted area is ideal because it allows rainwater to slowly percolate into the soil. Storage container inlets and overflow outlets should be the same size.

Distribution. The distribution system directs water from the storage container to landscaped areas. The distribution device can be a garden hose, constructed channels, pipes, perforated pipes, or a manual drip system. Gates and diverters can be used to control flow rate and direction. A manual or electric valve located near the bottom of the storage container can assist gravity-fed irrigation. In the absence of gravity flow, an electric pump hooked to a garden hose can be used. Distribution of water through an automatic drip irrigation system requires extra effort to work effectively. A pump will be required to provide enough pressure to operate a typical drip irrigation system.

To continue using a drip or other integrated distribution system in the event of a rainwater shortfall, and to avoid the need for dual systems, provisions should be made for adding water to your container or distribution system from an auxiliary source. Connection of the distribution system to a municipal or private water supply requires the use of an “air gap” or other approved backflow prevention device. If such a source is unavailable, ensure your pump will turn off automatically when there is no water in the tank. These integrated distribution systems can be rather complex: check your local plumbing and building codes to ensure your system is in compliance.

COMPLEX RAINWATER HARVESTING SYSTEM DESIGN & CONSTRUCTION

If you are designing a complex water harvesting system — one that includes storage to provide rainwater in between rainfall events — advance planning, coupled with a few simple calculations, will result in a more functional and efficient system. The steps involved in designing a complex water harvesting system include site analysis, calculation, design, and construction. If the project is a complicated one, either because of its size or because it includes numerous catchments and planting areas, divide the site into sub-drainage areas and repeat the following steps for each sub-area. As a final step, field-test the system.



Roof catchment with multiple storage cans connected to a hose adjacent to a landscape holding area.

Step #1: Site Analysis. Whether you are designing a new landscape or working with an existing one, draw your site and all the site elements to scale. Plot existing drainage flow patterns by observing your property during a rain. Show the direction of water flow with arrows, and indicate high and low areas on your plan. Look for catchments, such as paved areas, roof surfaces, and bare earth.

Next, identify areas that require irrigation and sites near those areas where above or underground storage can be located. Although the final design will depend on the outcome of your supply and demand calculations (see below), consider how you are going to move water from the catchment to the holding area or storage container. Rely on gravity to move water whenever you can. Consider too how you are going to move water through the site from one landscaped area to another. Again, if the site is too large or the system too complicated, divide the site into sub-drainage areas.

Step #2: Calculations. First, calculate the monthly Supply (rainfall harvest potential) and the monthly Demand (plant water requirement) for a year. Next, calculate the monthly Storage/Municipal Water Requirement. Calculate Supply—The following equation for calculating supply will provide the amount of water (in gallons) that can be harvested from a catchment.

$$\text{SUPPLY (in gallons)} = \begin{matrix} \text{Inches} \\ \text{of} \\ \text{Rainfall} \end{matrix} \times .623 \times \begin{matrix} \text{Catchment} \\ \text{Area} \\ \text{(square feet)} \end{matrix} \times \begin{matrix} \text{Runoff} \\ \text{Coefficient} \end{matrix}$$

CALCULATING SUPPLY

RAINFALL TABLES

Monthly average rainfall amounts for 39 different locations in New Mexico are listed in Appendix I on page 18.


Multiply rainfall in inches (see Appendix I) by .623 to convert inches to gallons per square foot, and multiply the result by the area of catchment in square feet (ft²). (For example, a 10' x 20' roof is 200 ft². For a sloped roof, measure the area covered by the entire roof, which is usually the length and width of the building.) Multiply this figure by the “runoff coefficient” (see Appendix III) to obtain the available supply. (The runoff coefficient is the percentage of total rainfall that can be harvested from a particular surface. The “High” number in the table corresponds to a less absorbent surface, and the “Low” number corresponds to a more absorbent surface.)

EXAMPLE 1: CALCULATING SUPPLY

Eva wants to build a rainwater harvesting system for her home in Albuquerque. From Appendix I, she enters the rainfall for each month on the Supply Worksheet (see sample on next page). Then she multiplies the inches of rainfall by 0.623 to convert inches to gallons per square foot.

Eva has an “L”-shaped house with asphalt shingle roofing that she plans to use as her primary catchment area. To simplify measurements, she divides the house into two rectangular sections, A and B. The eave-to-eave measurements for section A are 45' x 25', and for section B are 20' x 25':

Section A	$45' \times 25' = 1,125 \text{ ft}^2$
Section B	$20' \times 25' = 500 \text{ ft}^2$
Total	$1,625 \text{ ft}^2$



Eva has 1,625 square feet of catchment area. She enters this value in Column C, then multiplies the gallons per SF in Column B by the square footage in Column C to determine the total gallons of rainfall each month. Since the asphalt shingle roof won't shed all of the rainfall, Eva finds the appropriate runoff coefficient (0.9) in Appendix II and enters it in Column E.

Multiplying Column D by Column E provides the net harvestable rainfall for the month.

SAMPLE SUPPLY WORKSHEET

	A	B	C	D	E	F
Follow the lettered instructions for each month.	From Appendix I enter the rainfall amount in inches for each month.	Multiply "A" by 0.623 to convert inches to gallons per square foot.	Enter the square footage of the catchment surface.	Multiply "B" by "C." This is the gross gallons of rainfall per month.	From Appendix II enter the runoff coefficient for your catchment surface.	Multiply "D" by "E." This is the total monthly yield of harvested water in gallons.
January	0.39	0.243	1,625	395	0.9	355
February	0.40	0.249	1,625	405	0.9	365
March	0.48	0.299	1,625	486	0.9	437
April	0.50	0.312	1,625	507	0.9	456
May	0.61	0.380	1,625	618	0.9	556
June	0.65	0.405	1,625	658	0.9	592
July	1.31	0.816	1,625	1,326	0.9	1,193
August	1.52	0.947	1,625	1,539	0.9	1,385
September	1.02	0.635	1,625	1,032	0.9	929
October	0.81	0.504	1,625	819	0.9	737
November	0.48	0.299	1,625	486	0.9	437
December	0.49	0.305	1,625	496	0.9	446
Annual Totals	8.66			8,767		7,888

SAMPLE DEMAND WORKSHEET (METHOD 1)

	A	B	C	D	E	F
Follow the lettered instructions for each month.	From Appendix III enter the ET amount in inches for each month.	From Appendix IV enter the plant demand according to its water needs.	Multiply "A" by "B" to obtain plant water needs in inches.	Multiply "C" by 0.623 to convert inches to gallons per square foot.	Enter the total square footage of landscaping.	Multiply "E" by "D." This is your total landscaping demand in gallons.
January	0.38	0.50	0.19	0.12	1,200	142
February	0.64	0.50	0.32	0.20	1,200	239
March	1.44	0.50	0.72	0.45	1,200	538
April	2.76	0.50	1.38	0.86	1,200	1,032
May	4.58	0.50	2.29	1.43	1,200	1,712
June	6.37	0.50	3.18	1.98	1,200	2,381
July	7.17	0.50	3.58	2.23	1,200	2,680
August	6.43	0.50	3.21	2.00	1,200	2,404
September	4.42	0.50	2.21	1.38	1,200	1,652
October	2.52	0.50	1.26	0.78	1,200	942
November	0.93	0.50	0.46	0.29	1,200	348
December	0.46	0.50	0.23	0.14	1,200	172
Annual Totals	38.1		23.75			14,242

CALCULATING DEMAND

Calculate Demand – The demand equation tells how much water is required for a given landscaped area. Two methods are available for determining landscape demand: Method 1 can be used for either new or established landscapes; Method 2 can be used for established landscapes only. (HELPFUL HINT: When installing a new landscape, group plants with similar water requirements together. This makes it easier to calculate the amount of water needed to maintain those plants.)

CALCULATING DEMAND, METHOD 1 :

DEMAND = ET (in inches) x PLANT FACTOR x .623 x IRRIGATED AREA

This method for calculating demand is based on monthly evapotranspiration (ET) information. (Appendix III provides ET information for six different regions in New Mexico.) ET is multiplied by the “Plant Water Use Coefficient,” which represents the percentage of ET needed by the plant. (See Appendix IV for information on plant coefficients. In the example that follows, the plants require approximately 50 percent of ET.) Irrigated area refers to how much area is planted. (Do not include unplanted portions of the landscape in your calculation of demand.)

EXAMPLE 2: CALCULATING DEMAND

New or Established Landscape (Method 1)

Eva’s landscape has a small lawn area served by a sprinkler system and about 1,200 square feet of densely planted moderate water use trees, shrubs and flowers. To avoid the expense of installing an electric pump, Eva wants her rainwater project to operate by gravity flow. Since the sprinkler system cannot be operated by gravity flow, she decides to limit the use of her rainwater system to irrigation of her flowers, trees and shrubs.

1. Using the Demand Worksheet (see sample on previous page), Eva calculates the potential water needs (demand) for her rainwater-irrigated area. From Appendix III, she enters the evapotranspiration rate for the Albuquerque area into Column A.
2. Since Eva’s landscape is primarily moderate water use plants, she uses a plant coefficient of 0.5 (see Appendix IV). She enters this value in Column B.
3. She then multiplies A by B to get the estimated number of inches of water her plants will require. She enters the result in Column C.
4. She multiplies Column C by 0.623 to convert inches to gallons per square foot and enters the result in Column D.
5. In Column E, she enters the total square feet of landscaping she hopes to water with her rainwater system.
6. Lastly, she multiplies Column D by Column E to determine how much water her landscape will need for each month.

Now that the supply and demand have been calculated for each month, Eva can determine the maximum storage needs for her system. Although containers of any size will reduce Eva’s dependence on municipal water, to fully capitalize on the available rainfall she should have enough storage to accommodate her cumulative water storage needs (see Sample Worksheet on page 15 and sidebar on page 16).

CALCULATING DEMAND

CALCULATING DEMAND, METHOD 2 :

This method estimates landscape water demand based on actual water use, as measured by your monthly water bills. With this method, we assume that most water used during the months of December through March is indoor use, and that very little landscape watering occurs. (If you irrigate your landscape more than occasionally during these months, use Method 1.) Most utilities measure water in ccf (1 ccf = 100 cubic feet. In Albuquerque, 1 unit of water = 1 ccf). To use this method, combine the water use amounts for December, January and February, and divide by 3 to determine your average indoor water use. In the worksheet that follows, the average winter monthly use is 9 ccf. Because we can assume that indoor use remains relatively stable throughout the year, simply subtract the average winter monthly use from each month's total use to obtain a rough estimate of monthly landscape water use. To convert ccf to gallons, multiply ccf by 748.

SAMPLE DEMAND WORKSHEET (METHOD 2)

Established Landscapes

Average Winter Consumption=9 CCF

Month	Monthly Use in CCF	Average Winter Use in CCF	Landscape Use in CCF	Convert CCF to Gallons	Landscape Use in Gallons
Jan	7	9	0	748	0
Feb	11	9	2	748	1,496
Mar	13	9	4	748	2,992
Apr	15	9	6	748	4,488
May	18	9	9	748	6,732
Jun	19	9	10	748	7,480
Jul	18	9	9	748	6,732
Aug	15	9	6	748	4,488
Sep	14	9	5	748	3,740
Oct	12	9	3	748	2,244
Nov	10	9	1	748	748
Dec	9	9	0	748	0

WHAT IS EVAPOTRANSPIRATION?

Evapotranspiration, usually referred to as "ET" for convenience, is the combined loss of water from the soil due to evaporation and plant transpiration. It is usually expressed in inches. To keep a plant healthy, water must be replenished in relation to the ET rate.

Weather and plant types are the primary factors that determine ET. On the weather side, temperature, wind, solar radiation, and humidity are the important variables.

ET usually is calculated for alfalfa, a heavy water use crop. Since most plants don't use as much water as alfalfa, the ET rate is multiplied by a plant coefficient that adjusts the ET rate for the types of plants you are growing.

Calculate Storage/Municipal Water Requirement. Once you've calculated the potential water supply from harvested water and your landscape water demand, use a "checkbook" method to determine your monthly harvested water balance and the amount of supplemental water (municipal or other source) needed to meet any shortfall in stored rainwater. The calculations in the sample worksheet that follows are based on the sample supply and demand calculations presented earlier (see the sample worksheets on page 12), which in turn are based on the supply and demand scenario presented in Examples 1 and 2. For the sake of simplicity, the calculations in this worksheet are performed on a monthly basis. In reality, the amount of water available fluctuates daily.

CALCULATING CUMULATIVE STORAGE & MUNICIPAL USE

The “Storage” column in this completed worksheet is cumulative and refers to what is actually available in storage. A given month’s storage is obtained by adding the previous month’s storage to the current month’s yield, minus the current month’s demand. If the remainder is positive, it is placed in the Cumulative Storage column for the current month. This number is then added to the next month’s yield to provide for the next month’s demand. If the remainder is negative, that is, if the demand is greater than the supply of stored water, this number is placed in the Municipal Use column to indicate the amount of supplemental water needed to satisfy irrigation water demand for that month.

SAMPLE STORAGE/MUNICIPAL USE WORKSHEET

Month	Yield Gallons	Demand Storage	Cumulative Storage Gallons (yield-demand)	Municipal Use
<u>Year 1</u>				
Jan*	355	0	355	0
Feb*	365	0	720	0
Mar	437	538	619	0
Apr	456	1,032	43	0
May	556	1,712	0	1,113
Jun	592	2,381	0	1,789
Jul	1,193	2,680	0	1,487
Aug	1,385	2,404	0	1,019
Sep	929	1,652	0	723
Oct	737	942	0	205
Nov	437	348	89	0
Dec*	446	0	535	0
<u>Year 2</u>				
Jan*	355	0	890	0
Feb*	365	0	1,255	0
Mar	437	538	1,154	0
Apr	456	1,032	578	0
May	556	1,712	0	578
Jun	592	2,381	0	1,789
Jul	1,193	2,680	0	1,487
Aug	1,385	2,404	0	1,019
Sep	929	1,652	0	723
Oct	737	942	0	205
Nov	437	348	89	0
Dec*	446	0	535	0

*No demand is shown for the months of December through February in this example because it assumes rain falling on the landscape will be sufficient to meet water demand for those months, and that all harvested water will be put into storage. (Though not reflected here, November and March should also experience less demand for the same reason.)

BALANCING SUPPLY AND DEMAND

CALCULATING YOUR MAXIMUM STORAGE REQUIREMENTS

To determine your maximum storage requirements, find the largest number in the cumulative storage column for year 2 on the preceding page. In that example, February is the month with the most water in storage: 1,255 gallons. That figure represents the maximum amount of storage capacity required, which means that a container with approximately 1,300 gallons of storage capacity would suffice.

As shown on the preceding page, Eva's landscape demand during the summer months will always require the use of a supplemental water supply. The supply of rainwater exceeds demand during the winter months when evapotranspiration rates are low, so this water can be saved for the "leaner" spring and early summer months.

Every site presents its own unique set of water supply and demand amounts. Some water harvesting systems may always provide enough harvested water to meet demand, while others may provide only part of the demand. Remember that the supply will fluctuate from year to year, depending on the weather and the month in which rainfall occurs. Demand may increase when the weather is warmer than normal, and will increase as the landscape ages and plants grow larger. Demand will also be greater during the period of time when new plants are getting established.

If, after determining the available supply and demand, it turns out that the supply of harvested water falls short of meeting irrigation demands, you can balance your water harvesting checkbook by either increasing the supply or by reducing the demand.

Options for increasing the supply include the following:

- * Increase the catchment area or catchment (runoff) coefficient
- * Use municipal or some other source of water

Options for reducing demand include the following:

- * Reduce the amount of landscaped area
- * Reduce the plant density
- * Replace high-water use plants with lower-water use plants
- * Use mulch to reduce surface evaporation

Step #3. Final design and construction—Use your site analysis information and your potential supply and demand calculations to size and locate catchment areas. If possible, size the catchment to accommodate the maximum landscape water requirement. If you cannot do this you may want to reduce plant water demand by either lowering planting density or by selecting lower water use plants. Roofs or shade structures can be designed or retrofitted to maximize the size of the catchment area. If you are planning a new landscape, create one that can live on the amount of water harvested from the existing roof catchment. This can be accomplished through careful plant selection and by controlling the number of plants used. For the most efficient use of harvested water, group plants with similar water requirements together. Remember that new plantings, even native plants, require special care and will need supplemental irrigation during the establishment period. This period can range from one to three years. (Use the supply and demand calculations to determine the amount of


water needed for new plantings.) Use gutters and downspouts to convey the water from the roof to the storage area. (Consult Appendix VI for tips on selecting and installing gutters and downspouts.)

Size storage container(s) large enough to hold your calculated supply. Provide for distribution to all planted areas. Locate storage close to plants needing water and higher than the planted area to take advantage of gravity flow. Pipes, hoses, channels, and drip systems can distribute water where it is needed. If you do not have gravity flow or if you are distributing through a drip system, you will need to use a small pump to move the water through the lines. Select drip irrigation system filters with 200-mesh screens. The screens should be cleaned regularly.


System Maintenance. Developing a water harvesting system is actually an ongoing process that can be improved and expanded over time. Once the initial construction is complete, it will be necessary to “field test” your system during rain events. Determine whether the water is moving where you want it, or whether you are losing water. Also determine if the holding areas are doing a good job of containing the water. Make changes to your system as required. As time goes on you may discover additional areas where water can be harvested or channeled. Water harvesting systems should be inspected before each rainy season — and ideally after every rain event — to keep the system operating at optimum performance.

GRAVITY FLOW TIP BOX

GRAVITY FLOW EQUALS .433 POUNDS PER SQUARE INCH FOR EACH FOOT OF ELEVATION.



Gutter leaf filter.



Parking lot curb cutout directing water into planted area.

TABLE-1
MAINTENANCE CHECKLIST

- Keep holding areas free of debris.
- Control and prevent erosion; block erosion trails.
- Clean and repair channels.
- Clean and repair dikes, berms, and moats.
- Keep gutters and downspouts free of debris.
- Flush debris from the bottom of storage containers.
- Clean and maintain filters, including drip filters.
- Expand watering basins as plants grow.
- Monitor Water Use.

Once your system is operating, it's recommended that you monitor landscape water use so you'll know just how much water you're saving. If you've constructed water harvesting basins in an existing landscape, use last year's water bills to compare your pre-harvesting and post-harvesting water use. If you're adding new plants to a water harvesting area, the water savings begin as soon as they're in the ground, and the savings continue every time they're irrigated with harvested rainwater!

APPENDIX I

**NM Towns	*INCHES OF AVERAGE MONTHLY RAINFALL FOR NM TOWNS												
	Jan.	Feb.	Mar.	April	May	June	July	Aug.	Sept.	Oct.	Nov.	Dec.	Annual
Abiquiu Dam	0.38	0.26	0.51	0.55	0.83	0.71	1.59	2.01	1.13	0.88	0.53	0.34	9.71
Alamogordo	0.73	0.52	0.46	0.32	0.50	0.83	2.13	2.13	1.68	1.05	0.54	0.81	11.68
Albuquerque	0.39	0.40	0.48	0.50	0.61	0.65	1.31	1.52	1.02	0.81	0.48	0.49	8.66
Animas	0.70	0.54	0.49	0.19	0.17	0.45	2.20	2.36	1.46	0.99	0.57	1.03	11.15
Belen	0.28	0.40	0.40	0.26	0.31	0.63	1.40	1.32	0.90	0.98	0.20	0.39	7.45
Bernalillo	0.43	0.49	0.56	0.43	0.58	0.55	1.47	1.50	0.83	0.95	0.44	0.47	8.68
Carlsbad	0.43	0.44	0.30	0.53	1.24	1.53	1.73	1.96	2.34	1.24	0.49	0.51	12.72
Clayton	0.27	0.40	0.65	1.21	2.39	1.91	2.64	2.31	1.68	1.09	0.50	0.38	15.44
Clines Corners	1.05	0.82	0.99	1.00	1.60	1.61	2.72	3.16	2.24	1.49	1.04	1.00	18.71
Clovis	0.43	0.43	0.59	1.04	2.10	2.60	2.62	2.96	2.16	1.61	0.56	0.60	17.71
Corrales	0.43	0.39	0.67	0.65	0.68	0.82	1.63	1.95	1.18	0.85	0.91	0.64	10.80
Crownpoint	0.52	0.51	0.49	0.50	0.36	0.67	2.06	1.89	0.85	0.85	0.46	0.61	9.75
Cuba	0.89	0.69	0.88	0.68	0.80	0.80	2.07	2.28	1.38	1.11	0.80	0.72	13.09
Deming	0.48	0.54	0.34	0.20	0.16	0.37	2.07	1.90	1.22	0.79	0.52	0.89	9.50
Española	0.47	0.43	0.59	0.58	0.89	0.75	1.50	1.94	1.00	0.90	0.57	0.50	10.12
Estancia	0.54	0.53	0.64	0.55	1.01	0.97	2.19	2.38	1.51	1.13	0.64	0.80	12.87
Farmington	0.58	0.50	0.55	0.51	0.36	0.46	0.80	1.07	0.83	1.11	0.49	0.62	7.89
Fort Sumner	0.39	0.40	0.44	0.59	1.16	1.47	2.42	2.81	1.80	1.37	0.55	0.49	13.90
Gallup	0.89	0.73	0.89	0.53	0.64	0.47	1.54	1.93	1.13	1.00	0.99	0.74	11.50
Grants	0.51	0.43	0.52	0.45	0.57	0.57	1.71	2.10	1.35	1.10	0.56	0.66	10.52
Hobbs	0.48	0.45	0.46	0.80	2.09	1.83	2.16	2.42	2.66	1.58	0.57	0.58	16.06
Jemez Springs	1.08	0.88	1.02	0.89	1.07	1.07	2.61	3.12	1.58	1.50	1.06	0.94	16.83
Las Cruces	0.52	0.33	0.23	0.21	0.33	0.66	1.46	2.27	1.31	0.82	0.46	0.76	9.17
Los Alamos	0.91	0.79	1.10	0.94	1.31	1.38	3.14	3.78	1.82	1.42	0.98	0.98	18.53
Los Lunas	0.35	0.42	0.46	0.44	0.49	0.57	1.23	1.76	1.21	1.06	0.46	0.53	8.98
Pecos	0.66	0.65	0.86	0.73	1.14	1.29	3.00	3.48	1.86	1.09	0.80	0.63	16.21
Raton	0.37	0.39	0.71	0.91	2.51	2.25	2.87	3.34	1.88	0.92	0.49	0.41	17.07
Roswell	0.42	0.46	0.29	0.60	1.33	1.63	2.01	2.48	2.16	1.06	0.51	0.59	13.52
Ruidoso	1.17	1.20	1.21	0.63	0.94	1.94	4.05	4.03	2.65	1.54	0.85	1.63	21.85
Sandia Park	3.10	1.24	1.44	0.93	1.14	1.12	3.00	3.00	1.83	1.40	1.31	1.20	20.44
Santa Fe	0.65	0.74	0.79	0.94	1.33	1.05	2.35	2.17	1.52	1.11	0.62	0.71	13.99
Shiprock	0.51	0.43	0.46	0.40	0.52	0.32	0.63	0.98	0.67	0.86	0.57	0.59	6.93
Silver City	1.25	0.85	0.84	0.55	0.21	0.58	2.78	2.48	1.91	1.21	0.49	1.07	14.17
Socorro	0.39	0.39	0.33	0.37	0.59	0.62	2.59	1.77	1.46	0.97	0.37	0.56	10.40
Taos	0.71	0.63	0.83	0.77	1.17	0.89	1.62	1.98	1.25	1.03	0.84	0.68	12.40
Tijeras	0.63	0.97	1.06	0.90	0.78	0.88	2.45	2.42	1.57	1.46	0.80	1.18	15.10
T or C	0.47	0.37	0.33	0.21	0.42	0.81	1.72	2.11	1.37	0.96	0.54	0.96	10.26
Tucumcari	0.26	0.47	0.39	0.87	1.49	1.78	3.30	2.40	1.46	0.94	0.50	0.27	14.11
Vaughn	0.44	0.44	0.35	0.51	0.92	1.60	1.99	2.56	1.41	0.87	0.41	0.38	11.87

* Data obtained from the Western Region Climate Center and the National Oceanic and Atmospheric Agency

** The average rainfall for more specific locations may vary from the averages shown here. In Albuquerque, for example, average rainfall ranges from 8.51 inches a year at the airport to 14.00 inches a year near the Sandia foothills.

APPENDIX II

RUNOFF COEFFICIENTS		
	HIGH	LOW
<u>ROOF</u> Metal, gravel, asphalt shingle, fiberglass, mineral paper	0.95	0.90
<u>PAVING</u> Concrete, asphalt	1.00	0.90
<u>GRAVEL</u>	0.70	0.25
<u>SOIL</u> Flat, bare	0.75	0.20
Flat, with vegetation	0.60	0.10
<u>LAWN</u> Flat, sandy soil	0.10	0.05
Flat, heavy soil	0.17	0.13

APPENDIX III

Areas	*AVERAGE EVAPOTRANSPIRATION FOR SELECTED AREAS IN NM												
	Jan.	Feb.	Mar.	April	May	June	July	Aug.	Sept.	Oct.	Nov.	Dec.	Total
Northwestern Plateau (Gallup)	0	0.33	0.86	1.87	3.37	4.95	6.15	5.37	3.56	1.91	0.60	0	28.9
Northern Mtns. (Santa Fe)	0	0.30	0.68	1.56	2.82	4.26	5.05	4.51	3.02	1.63	0.52	0	24.3
Eastern Plains (Clovis)	0.35	0.55	1.27	2.53	4.31	6.23	7.00	6.30	4.26	2.42	0.91	0.45	36.5
Western Mtns. (Grants)	0.26	0.41	0.98	1.87	3.23	4.85	5.67	4.94	3.41	1.92	0.71	0.35	28.6
Central Valley (Albuquerque)	0.38	0.64	1.44	2.76	4.58	6.37	7.17	6.43	4.42	2.52	0.93	0.46	38.1
Central Highlands (Mountainair)	0.26	0.41	0.98	1.94	3.33	4.85	5.48	4.81	3.39	1.91	0.71	0.35	28.4
Southeastern Plains (Carlsbad)	0.52	0.78	1.68	3.10	4.95	6.79	7.33	6.66	4.69	2.84	1.17	0.66	41.1
Southern Desert (Las Cruces)	0.56	0.83	1.78	3.11	4.94	6.91	7.66	6.80	4.88	2.97	1.24	0.68	42.3

* Data obtained from the Toro Company, "Rainfall-Evapotranspiration Data," Form #490-1358

APPENDIX IV

PLANT WATER USE COEFFICIENTS	
PLANT TYPE	PERCENTAGE
Low Water Use	0.20
Medium Water Use	0.50
High Water Use	0.75

The Plant Water Use Coefficient represents the water needs of a particular plant relative to the rate of evapotranspiration (ET). Thus a low-water use plant requires only 20 percent of ET, but a high-water use plant requires 75 percent of ET. New plantings of all types require additional water. Supplemental water must be supplied in areas where a plant's water use requirement (demand) exceeds the amount of water available from precipitation (supply). If you're unsure of a plant's water use requirements, consult the City of Albuquerque's Xeriscape Guide.

Low water use plants include grasses such as Blue Grama and trees such as Desert Willow.
 Medium water use plants include grasses such as Buffalograss and trees such as Modesto Ash.
 High water use plants include grasses such as Kentucky Bluegrass and trees such as Globe Willow.



Demonstration Garden photo courtesy of Santa Fe Greenhouses, Santa Fe, New Mexico

APPENDIX V

WORKSHEET #1: SUPPLY CALCULATIONS

	A	B	C	D	E	F
Follow the lettered instructions for each month.	From Appendix I enter the rainfall amount in inches for each month.	Multiply "A" by 0.623 to convert inches to gallons per square foot.	Enter the square footage of the catchment surface.	Multiply "B" by "C." This is the gross gallons of rainfall per month.	Enter the runoff coefficient for your catchment surface.	Multiply "D" by "E." This is the total monthly yield of harvested water in gallons.
January						
February						
March						
April						
May						
June						
July						
August						
September						
October						
November						
December						
Totals						

WORKSHEET #2: DEMAND CALCULATIONS (METHOD 1)

	A	B	C	D	E	F
Follow the lettered instructions for each month.	From Appendix IV enter the ET amount in inches for each month.	From Appendix V enter the plant demand according to its water needs.	Multiply "A" by "B" to obtain plant water needs in inches.	Multiply "C" by 0.623 to convert inches to gallons per square foot.	Enter the total square footage of landscaping.	Multiply "E" by "D." This is your total landscaping demand in gallons.
January						
February						
March						
April						
May						
June						
July						
August						
September						
October						
November						
December						
Totals						

WORKSHEET #3:
DEMAND CALCULATIONS
(METHOD 2)

Month	Monthly Use in CCF	Average Winter Use in CCF	Landscape Use in CCF	Convert CCF to Gallons	Landscape Use in Gallons
Jan					
Feb					
Mar					
Apr					
May					
Jun					
Jul					
Aug					
Sep					
Oct					
Nov					
Dec					

WORKSHEET #4:
STORAGE/MUNICIPAL USE
CALCULATIONS

Month	Yield Gallons	Demand Storage	Cumulative Storage Gallons (yield-demand)	Municipal Use
<u>Year 1</u>				
Jan				
Feb				
Mar				
Apr				
May				
Jun				
Jul				
Aug				
Sep				
Oct				
Nov				
Dec				
<u>Year 2</u>				
Jan				
Feb				
Mar				
Apr				
May				
Jun				
Jul				
Aug				
Sep				
Oct				
Nov				
Dec				

APPENDIX VI

GUIDELINES FOR GUTTERS AND DOWNSPOUTS

Gutters and downspouts are key components of the system for distributing rainwater to plants. They should be properly sized and durable, but they should also be attractive and well-suited to the building they're used on.


The following are general guidelines for the use of gutters and downspouts. Particular applications may vary, depending on the type of gutter selected and any special considerations, such as snow load or roof type. Consult a company that specializes in gutter design and installation for more information.

GUTTERS

- Select gutters that are at least 5 inches wide.
- Select galvanized steel (29-gauge minimum) or aluminum (.025-inch minimum) gutters.
- To enhance flow, slope sectional gutters 1/16 of an inch per 1 foot of gutter; slope seamless gutters 1/16 of an inch per 10 feet.
- If a straight run of gutter exceeds 40 feet, use an expansion joint at the connection.
- Keep the front of the gutter 1/2 inch lower than the back.
- Provide gutter hangers at least every 3 feet. Space hangers every 1 foot in areas of heavy snow load.
- Select elbows in 45, 60, 75, or 90-degree sizes.

DOWNSPOUTS

- Space downspouts from 20 to 50 feet apart.
- Provide 1 square inch of downspout area for every 100 square feet of roof area. A 2-inch by 3-inch downspout will accommodate 600 to 700 square feet; a 3-inch by 4-inch downspout will accommodate up to 1,200 square feet.
- Do not exceed 45-degree angle bends.
- Select downspouts in configurations—square, round, and corrugated round, depending on your needs. Both gutters and downspouts come in a variety of maintenance-free finishes.
- Use 4-inch diameter pipe to convey water to the storage container or filter.




Gutter drain filter.

APPENDIX VII

HOW TO BUILD A RAIN BARREL

BUILDING YOUR OWN RAIN BARREL SYSTEM




Notes:

- Barrels weigh more than 400 pounds when full, so ensure they are secure and cannot be pulled over.
- Place the finished barrel on a wood pallet or sand platform, otherwise the bottom will bulge when full.
- Drill a 1/16-inch hole just below the rim of the barrel to vent the air when water rushes in.
- Only one barrel needs a hose bib.

PUTTING THE BARREL PARTS TOGETHER

Parts can be found in the plumbing and electrical sections of building supply stores. Used barrels may be obtained from detergent or bakery industries.

- 1** Use a hole saw to cut a hole slightly smaller than your 3/4- or 1-inch male threaded fitting, about 3 inches above the bottom of the barrel. Enlarge with a file just enough so the threaded end of the fitting will slide in tightly.
- 2** Make a rubber washer from a flat rubber pad (use the same hole saw for the hole, then cut the outside with scissors). Push the washer over the threads of the fitting so it's snug. Apply a large bead of silicone caulk to the washer.



- 3** Slide a wire or string down through the hole at the top of the barrel, thread it through the new hole at the bottom, and use it to guide the fitting into position. Pull the threaded end to the outside. Screw on a threaded electrician's lock nut to tighten. Allow caulk to dry several hours. Remove lock nut and add caulk near hole before adding next fitting.
- 4** Wrap teflon tape around the threads and screw on a female threaded tee fitting.
- 5** Glue a PVC connector for the faucet on one slip-joint end of the tee. On the other end, glue a short piece of PVC pipe. Attach a cap to this end, or if you're adding another barrel, slide on a length of polyvinyl black hose and tighten with a screw clamp.

Source: Albuquerque Journal, June 26, 1999

Carol Cooperider

Used with Permission

APPENDIX VIII

WHERE TO GO FOR MORE INFORMATION

PUBLICATIONS

- Introduction to Permaculture, by Bill Mollison. Tagari Publications, 1988.
- The Negev—The Challenge of a Desert, Second Edition, by Michael Evenari, Leslie Shanan, and Naphtali Tadmor. Harvard Press, 1982.
- “Water Harvesting Traditions in the Desert Southwest,” by Joel Glansburg, in the Permaculture Drylands Journal, #30, pp. 25-27. Permaculture Institute, USA, Summer 1998.
- “Water Conservation Through an Anasazi Gardening Technique,” by Carleton S. White, David R. Dreesen, and Samuel R. Loftin in the New Mexico Journal of Science, Volume 38, pp. 251-278. New Mexico Academy of Science, November 1998.
- Ferrocement Water Tanks and Their Construction, by S.B. Watt. Intermediate Technology Publications, 1978.
- “Constructing Quick and Inexpensive Water Cisterns for Zone One Use,” by Dan Dorsey in the Permaculture Drylands Journal #24, pp. 8-10. Permaculture Institute, USA, December 1995.

OTHER RAINWATER HARVESTING GUIDES

- Texas Guide to Rainwater Harvesting, Second Edition, by Wendy Price Todd and Gail Vittori. Texas Water Development Board, 1997.
- Harvesting Rainwater for Landscape Use, by Patricia H. Waterfall. Arizona Department of Water Resources, 1998.

ORGANIZATIONS

American Rainwater Catchment Systems Association
 P.O. Box 685283
 Austin, TX 78768-5283

Center for Maximum Potential Building Systems
 8604 E.M. 969
 Austin, TX 78724
 (512) 928-4786

Permaculture Institute, USA
 Casa Las Barrancas Farm
 P.O. Box 3702
 Pojoaque, NM 87501

Green Builders Program, Home Builders Association of Central New Mexico
 5931 Office Blvd. NE
 Albuquerque, NM 87109
 (505) 344-3294



City of Albuquerque
Jim Baca, Mayor

P.O. Box 1293
Albuquerque, NM 87103

Appendix B: NMED Ground
Water Quality Bureau NOI
Guidance for Green
Infrastructure that may qualify
as a Class V UIC Well

Appendix B – GWQB Permitting Requirements

There are three cases regarding stormwater runoff infiltration and determination of Class V well requirements.

1. NOT A CLASS V WELL, NO FORMS SUBMITTED

- a. Shallow surface infiltration such as a retention pond. This is an open water surface feature.
 - i. Example: 15' wide, 50' long, 3' deep pond with overtopping outlet
- b. Shallow trench backfilled with natural material. Note that the regulation states that if the infiltration trench is “deeper than its widest surface dimension” it may be considered a Class V well and fall under 2.a below. When in doubt check with NMED early on in the design.
 - i. Example: 5' wide, 40' long, 5' deep trench backfilled with pea gravel, with filter fabric between the soil and pea gravel.

2. A NON-PERMITTED CLASS V WELL - Two one-page forms to submit: Notice of Intent (NOI) *and* Underground Injection Control (UIC) Well Inventory. Once these forms are submitted and processed NMED will send a letter stating that no Permit is required.

- a. Relatively shallow infiltration systems that include man-made devices to distribute fluids below normal surface grade. There is no specific cutoff depth to define “relatively shallow”, but most infiltration trenches the DOT would design would likely be considered shallow. This category is appropriate for parking lots or highway/road drainage, as compared to 3.b below. Again, if in doubt, contact NMED.
 - i. Example: a 5' wide, 40' long, 5' deep gravel-filled infiltration trench which has either a vertical perforated pipe in the gravel layer, or horizontal distribution pipes in the gravel layer, or both.
- b. Are there any annual reports or other documents that need to be filed?
 - i. Generally, for residential and light commercial (e.g., retail parking lots) NMED does not require any periodic monitoring. If the facility has a potential greater than the previously described to contain and discharge contaminant(s), NMED may require some sort of monitoring and reporting, perhaps tied to a rain event. Check with NMED when in doubt.
- c. Is a Notice of Termination required if the infiltration trench is destroyed, removed, or taken out of service?
 - i. Yes, NMED requires notification if the system is “permanently abandoned” which can include its destruction or removal. If a system is just taken out of service for a period of time, even a year, but it is expected to be used again, then we do not need to be notified. If a system is taken out of service permanently (e.g., a building is raised or road is removed) then the system needs to be “closed” which usually entails filling in impoundments, plugging and abandoning vertical wells, plugging pipes, and removing or demolishing tanks as well as notifying NMED.

3. A PERMITTED CLASS V WELL - Two one-page forms as in 2.a above are submitted first, and when NMED responds (within 60 days of receipt) with a letter stating that a Discharge Permit is required, a Ground Water Discharge Permit Application (18 pages) must be submitted within the deadline in the letter. In some cases, if it is certain that a Discharge Permit is required based on discussion with NMED, the two one-page forms can be omitted to expedite the process for receiving a Discharge Permit.

- a. An injection or recharge system that is not shallow and uses man-made devices to distribute fluids
 - i. Example: a 200' deep injection well
- b. A relatively shallow infiltration system that otherwise could be considered as 2.a above, but which collects runoff from an area that is likely to contain a higher concentration of contaminants.
 - i. Example: a patrol yard or maintenance facility that drains to a shallow infiltration trench.

Short version...

Current NMED requirements for stormwater infiltration permitting and documentation.

1. NOT A CLASS V WELL, NO FORMS SUBMITTED

- a. Shallow surface infiltration such as a retention pond. This is an open water surface feature.
- b. Shallow trench backfilled with natural material.

2. A NON-PERMITTED CLASS V WELL

- a. Two one-page forms to submit:
 - i. Notice of Intent (NOI)
 - ii. Underground Injection Control (UIC) Well Inventory.
 - iii. Once these forms are submitted and processed NMED will send a letter stating that no Permit is required.
- b. Relatively shallow infiltration systems that include man-made devices to distribute fluids below normal surface grade. This category is appropriate for parking lots or highway/road drainage, as compared to 3.b below. Again, if in doubt, contact NMED.
- c. Generally, for residential and light commercial (e.g., retail parking lots) NMED does not require any periodic monitoring. If the facility has a potential greater than the previously described to contain and discharge contaminant(s), NMED may require some sort of monitoring and reporting, perhaps tied to a rain event. Check with NMED when in doubt.
- d. Notice of Termination required if the infiltration trench is destroyed, removed, or taken out of service.

3. A PERMITTED CLASS V WELL

- a. An injection or recharge system that is not shallow and uses man-made devices to distribute fluids
- b. Two one-page forms as in 2.a above are submitted first, and when NMED responds (within 60 days of receipt) with a letter stating that a Discharge Permit is required, a Ground Water Discharge Permit Application (18 pages) must be submitted within the deadline in the letter.